


INSTALLATION INSTRUCTIONS: V70, V701, V71, & V72 FIXTURES



CAUTION

1. The electrical power must be disconnected from the fixture and pole before installing, servicing, or relamping the fixture.
2. These directions must be read carefully and adhered to. Failure to do so may result in injury, damage to the fixture, and voiding the warranty.

TOOLS REQUIRED

FOR INSTALLATION & RELAMPING

1. 5/32" Allen wrench
2. Wire connectors for appropriate wire
3. Phillips head screw driver
4. 1/2" Socket wrench



This fixture is intended for installation in accordance with the National Electrical Code and local code specifications. Failure to adhere to these codes and instructions may result in serious injury and/or damage to the ballast and void the warranty. These instructions do not purport to cover all details or variations in equipment, nor to provide for every possible contingency related to installation, operation, maintenance, or mounting situation. Should specific problems occur that are not addressed by these instructions, contact your Sales Representative or distributor for assistance. Retain these instructions for future reference.

INSTALLATION

WARNING - The power **MUST** be turned off prior to proceeding. Read these instructions carefully. If any problems are encountered that are not covered in these instructions, contact HADCO for assistance.

- STEP 1: Loosen the (4) set screws and lock nuts that secure the globe to the fixture.
Lift the globe off of the fixture.
- STEP 2: Using wire nuts, connect the incoming power supply wires to the fixture supply wires.
- STEP 3: Mount the housing onto a 3" post shaft or tenon.
Use the post fitter's 5/16-18 set screws, supplied by HADCO, to secure the housing to the post shaft or tenon.
- STEP 4: Install the correct lamp as specified on the lamp label next to the socket.
- STEP 5: Replace globe and tighten globe set screws and lock nuts.
- STEP 6: Connect power and test the fixture for proper operation.

TO REPLACE LAMP

NOTE: It is a good idea to clean the fixture each time you relamp. Avoid using harsh solvents or abrasives.

- STEP 1: Remove the globe. See STEP 1 from INSTALLATION above.
- STEP 2: Remove the old lamp and dispose of it in accordance with local codes and regulations.
- STEP 3: Install a new lamp, referring to the lamp label next to the socket to ensure using the correct type.
- STEP 4: Replace the globe and tighten the globe set screws and lock nuts.

TO REPLACE BALLAST

- STEP 1: Remove globe. See STEP 1 from INSTALLATION above. Remove lamp.
- STEP 2: Remove (4) screws holding ballast cover. Lift ballast cover and remove capacitor and/or ignitor under ballast cover.
- STEP 3: Remove wire connectors connecting incoming supply wires to fixture wires.
- STEP 4: Remove (2) screws holding ballast to ballast housing. Remove ballast.
- STEP 5: Make sure that the current lamp type and wattage correspond with the NEW ballast type and wattage.
- STEP 6: Check the NEW ballast for correct voltage.
- STEP 7: Install the new ballast and capacitor/ignitor in place of the old one.
- STEP 8: Reconnect the wires with wire connectors. Replace ballast cover.
- STEP 9: Replace lamp and globe and tighten globe set screws.

DISCLAIMER

While we believe these instructions to be accurate at the time of publication, HADCO reserves the right to make changes to this fixture and/or components. The contractor should follow local and National Electrical Codes where required. For any further information please contact HADCO customer service.

