

**Read and understand these instructions before installing luminaire.**

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding. Allow fixture to cool before handling.

**Retain these instructions for maintenance reference.**

## INSTRUCTIONS FOR ATTACHING VERTICAL BLADE LOUVER 81LV4 OR 81LV6 TO MINI HID WALL WASHERS

**NOTE:** GLASS LENS must always be installed as shown in FIG. 1 for proper luminaire operation and safety (See luminaire instruction sheet IS:81F)

**TO ATTACH LOUVER TO LUMINAIRE:**

1. Turn off power to LUMINAIRE.
2. Simultaneously press LOUVER's upper and lower TABS toward each other. (FIG.1)
3. Insert LOUVER's four SPRING TABS into top and bottom GROOVES of LUMINAIRE. (FIG.3)
4. Release SPRING TABS (FIG. 1,2,3)

**TO REMOVE LOUVER FROM LUMINAIRE:**

1. Turn off power to LUMINAIRE.
2. Simultaneously press LOUVER's upper and lower TABS toward each other.
3. Pull LOUVER away from LUMINAIRE

