

## INSTALLATION INSTRUCTIONS FOR MR16/ES16 TRIM IN PRE-WIRED INCANDESCENT 12V OR 120V MOUNTING FRAME

**ATTENTION:** Read and understand these instructions before installing fixture. This fixture is intended for installation in accordance with the National Electrical Code or Canadian Electrical Code (if applicable) and local regulations. To ensure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding. **Retain these instructions for maintenance reference.**

### A. HOUSING INSTALLATION:

#### MOUNTING FRAME: (Fixed)

1. Take out the socket cover. (Fig.1)
2. Fit the socket cover onto the housing. (Fig.2)
3. Press the springs toward the inside of the housing and push the housing into the ceiling opening. (Fig.3)
4. Tighten the 2 screws to adjust the edge of the ceiling housing. (Fig.4)

#### POWER PACK: (Movable)

1. Remove the movable power pack from the ceiling. (Fig.5)
2. Screw the housing onto the power pack in which ever of the two slots that provides the correct spring position (0° or 90°). Turn and tighten the screw. (Fig.5)
3. Press the springs toward the inside of the housing. (Fig.3)
4. Insert the mounting frame back into the opening.
5. Tighten the 2 screws on the housing to adjust the edge of the housing to the ceiling. (Fig.4)

### B. TRIM: (Fig.6)

1. Push the socket through the opening.
2. Push springs inwards and slide in housing.

**CAUTION:** Lamp manufacturer recommends that the protective glass be in place before energizing the lamp. Insure that the lamp is fully cooled before relamping.

### C. LAMP: (Fig.7)

1. Insert the pins on the lamp in the socket.
2. Place the protective glass on the lamp.
3. Install on the trim.

#### CAUTION: 303MRE

Do not use supply housing from trim if used with 303MRE power pack.

