

INSTALLATION INSTRUCTIONS

DESIGNER FLOOD (DF5/7) BARN DOOR ASSEMBLY



GARDCO LIGHTING
1611 Clovis Barker Road
San Marcos, TX 78666
www.sitelighting.com

443561001440 REV A

© COPYRIGHT 1988 GARDCO LIGHTING

NOTE: BARN DOOR ASSEMBLY SHOWN FROM MOUNTING SIDE. SHALLOW GROOVES ON BARN DOOR FLAPS SHOW IN THIS VIEW. DEEP STEPS ARE ON OPPOSITE SIDE.

TOOLS REQUIRED:

5/16 OPEN END WRENCH

3/32 HEX KEY (DF7) OR 5/64 HEX KEY (DF5)

#2 PHILLIPS SCREW DRIVER

1. INSERT MOUNTING BRACKET TABS INTO SLOTS IN THE LONG FLAPS. INSTALL HEX HEAD SCREWS AND TIGHTEN.
2. INSERT MOUNTING BRACKET TABS INTO SLOTS IN THE SHORT FLAPS. INSTALL HEX HEAD SCREWS AND TIGHTEN.
3. REMOVE AND DISCARD FILLER SET SCREWS FROM LENS FRAME. SECURE BARN DOOR ASSEMBLY TO LENS FRAME WITH PHILLIPS PAN HEAD SCREWS (SUPPLIED).
4. LOOSEN FLAP SCREWS, ADJUST FLAPS AS REQUIRED AND RETIGHTEN SCREWS.

