
Philips Lighting
www.philips.com

4422 003 92352
03/12
Printed in the Netherlands
Data subject to change

PSD-E



Maintenance instructions

To assure the lighting quality of this unique LED lighting concept there are only a few instructions regarding the maintenance of this luminaire:


☐ Do not touch electronic components!
Electronic components are under high voltage.
Electronic components are ESD sensitive.





☐ During installation or when maintaining the luminaire always use static free gloves to avoid marks on the luminaire.

☐ To remove dirt and spots use the following:
- o Dust: only use micro fiber cloths
- o Fingerprints, etc.: use a cleaner for synthetic materials with antistatic properties.



☐ Do not stare into the LED light beam.

☐ A LumiStone luminaire with DALI driver also support Touch and Dim functionality.

☐ This luminaire should not be used for illumination during building activities due to dirt and dust contamination.

LumiStone SP520P/SP522P/SP524P/SP526P

Installation instructions

Instructions de montage
Montageanleitung
Montage instruktie
Istruzioni di montaggio
Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning
Kokoonpano- ja kiinnitysohjeet
Montaj yönergesi
Οδηγίες συναρμολόγησης
Instrukcja montazu
Szerelési utasítások
Návod k montázi
ИНСТРУКЦИЯ ПО МОНТАЖУ
Návod k montáži


IP40 PSD | IP20 PSD-E | Class I | CE | EN 60598-2-5

All dimensions are in mm.


Weight table

SMTT / SMT1	5.1 kg max
DCB	6.3 kg max


DCB



SMTT




SMT1




Xitanium 75W/200V TD 230V	
Inrush Current Peak	48 (max) A
Mains current pulse time half peak	180 us
Earth leakage current	0.7 (max) mA
Number of drivers on MCB (16A type-B)*	20 (max)
Number of drivers connected to one 30mA residual current detector*	30 (max)


* verify per installation





PHILIPS


DCB











SMTT / SMT1

