

Installation instructions

Instructions de montage

Instrucciones de instalación

Kokoonpano- ja kiinnitysohjeet

Szerelési utasítások

Montageanleitung

Instruções de montagem

Montaj yönergesi

Návod k montáži

Montage instructie

Monteringsinstruktioner

Οδηγός συναρμολόγησης

ИНСТРУКЦИЯ ПО МОНТАЖУ

Istruzioni di montaggio







Monteringsvejledning








Instrukcja montażu

Návod k montáži



FBH020 2xPL-C/4P26W 127V	master 2xPLC 26W / 4p	0.41A Cosφ 0.9	0.8 m
FBH020 2xPL-C/4P26W 230V	master 2xPLC 26W / 4p	0.41A Cosφ 0.9	0.8 m
FBH020 2xPL-C/2P26W 230V	master 2xPLC 26W / 2p	0.65A Cosφ 0.45	0.8 m
FBH020 2xPL-C/4P18W 127V	master 2xPLC 18W / 4p	0.32A Cosφ 0.9	0.8 m
FBH020 2xPL-C/4P18W 230V	master 2xPLC 18W / 4p	0.32A Cosφ 0.9	0.8 m
FBH020 2xPL-C/2P18W 230V	master 2xPLC 18W / 2p	0.44A Cosφ 0.45	0.8 m





- F - Debrancher l'appareil avant de changer la lampe.
 UK - Disconnect the unit before changing the lamp.
 D - Vor den Auswechseln der lampe die Leuchte von der Netzspannung trennen.
 NL - Het apparaat uitschakelen alvorens de lamp te verwisselen.
 I - Spegner l'apparecchio prima di sostituire la lampada.
 SP - Desconecte el suministro de energía eléctrica antes de cambiar la lámpara.
 S - Apparaten Kopplas ifrån innan lampan byts.
 FI - Kytke yksikö irti ennen lampun vaihtoa.
 PL - Rozłączyć zespół przed wymianą lampy.
 P - Desligue a rede eléctrica antes de substituir a lampada.