

TCW 215/216

Installation instructions

Instructions de montage

Montagevoorschrift

Montážní návod

Installation instructions

Istruzioni di montaggio

Montážny návod

Montageanweisung


Instrucciones de montaje

Szerelési útmutató

4411 408 94352

Инструкции по установке

Instrukcja montażu



1

	A
18W	425 ± 75
36W	850 ± 75
49W	850 ± 75
58W	850 ± 75

2

ZCW216 HS

3

4

90°

5

T=110°C

10 40

10 10 40

9 < Ø < 13

L N

L N

0..10V =


0..10V =

6


! T=110°C

TCW 215


7



8




TW ...



TW3

0...10V=



TCW ... IK

