

34107/**/16



Gebruiksaanwijzing

Notice d'emploi

Benutzerhandbuch

User manual

Manual de usuario



PHILIPS

Incl.



A





B



C



Excl.





B





C




Type 1 p.4




Type 2 p.8




Type 1




1








2a




2b








8





Type 2








①






②











Philips Lighting Contact Centre
Int. Business Reply Service
I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven
Pays-Bas / The Netherlands

www.philips.com/homelighting
 +800 7445 4775

4404.018.36671
Last update: 22/01/13