


Power Vision




MVF024 Range

Installation Instruction 安装说明

3222 609 23721b





Product name 产品名称	Lamp 光源	Reflector/ Glass 反射器/玻璃	Voltage/ Hz 电压/频率	Lampholder 灯座	kg
MVF024	SON-T 1000W	WB MB	220V/ 50Hz	E40	16
	HPI-T 2000W				
	MHN-LA 1000W				




1. If the front glass is broken, switch off the main supply and replace the front glass.
切断电源, 更换玻璃。
2. Disconnect the unit before changing the lamp.
更换灯泡前, 请先切断电源。
3. Do not cover the luminaire with combustible.
灯具不允许被可燃物覆盖。



3




4




Aiming object through
a small hole and cusp
通过小孔和尖端瞄准目标



Aiming object through a dial
通过刻度盘调准对准目标



M10(2x)
45N.m



M20(3x)
114N.m