

# INSTRUCTION SHEET

ISF:300X

03-08/Rev-07

Tel.: (514) 636-0670 - Fax.: (514) 636-0460 www.canlyte.com

# INSTALLATION INSTRUCTIONS FOR 12V LOW VOLTAGE AND 120V REMODELER

Read and understand these instructions before installing the luminaire.

**CAUTION:** Branch circuit conductors must be rated 90°C. To prevent electrical shock turn off electricity and check your local electrical code and regulations. Consult a qualified electrician before installing.

WARNING: - Risk of fire: Transformer contains luminaire thermal protector. Use only replacement transformer obtained from Lightolier CFI.

Mounting Frame	Cut-Out		
	3-3/4" (95mm)	4-1/4" (108mm)	4-3/4" (121mm)
300MRX	X		
300MRSPX	X		
300ESX	X		
303MRE **	X		
3401MREX	X		x
400MRX			x
501X		X	

Note: Valid for 1-1/8" max. thickness of ceiling
\*\* Note: Valid for 1" max. thickness of ceiling

#### A. CEILING:

Cut an opening as indicated above. (Fig.1)
 <u>Note</u>: Ensure that there is nothing to obstruct the
 installation in the ceiling.

#### B. WIRE-IN:

- 1. Open junction box cover. (Fig.2)
- Insert the <u>supply lead</u> into the <u>junction box</u> with a BX connector (not included).
- 3. Ground the fixture.
- Connect the <u>white leads</u> (NEUTRAL) together, and the <u>black leads</u> (120V) or the red leads together.
- Close cover. (Fig.2) <u>Note</u>: Be careful not to pinch leads.

# C. MOUNTING FASTENERS FOR 303MRE

- 1. Press <u>springs</u> inwards on <u>housing</u>. (Fig.4)
- 2. Insert mountign frame in the appropriate opening.
- Tighten the <u>2 screws</u> on the housing to adjust the housing flange to the ceiling. (Fig.5) CAUTION: The housing must not be used for temporary lighting, a protective shield is required for the lamp, for the serie 300.

## D. TRIM:

- Install the trim using the appropriate instruction sheet.
- E. TRANSFORMER / REPLACEMENT: (Models 3401MRE, 303MRE,)

Note: Before performing maintenance on the transformer, make sure that the electrical supply to the fixture is turned off.

- Remove the <u>junction box</u> cover and disconnect all wiring connected to the transformer.
- The transformer is held by double sided tape, rotate with <u>screwdriver under the transformer</u> to loosen it. (Fig.4)
- Instal the new transformer and connect the <u>white</u> <u>leads</u> (NEUTRAL) together, and the <u>black leads</u> (120V) or the red leads (277V) together.

### NOTE: WARNING RISK OF FIRE

Transformer contains fixture thermal protector. Use only replacement transformer obtained from LIGHTOLIER.











