## READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE

This fixture is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electric shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

INSTRUCTION SHEET NO.

IS:1088

A0105

Page 1 of 1

# **INSTALLATION PROCEDURE FOR: 1088, 1088WH, 1088GW**

CAUTION: (RISK OF FIRE) FOR NON IC-RATED INSTALLATIONS, DO NOT INSTALL INSULATION ABOVE OR WITHIN 3 INCHES OF ANY PART OF FIXTURE.

CAUTION: USE ONLY REFLECTOR TRIMS PROVIDED BY LIGHTOLIER. USE OF OTHER MANUFACTURER'S REFLECTOR TRIMS MAY VOID THE UNDERWRITERS LABORATORIES LISTING AND COULD CONSTITUTE A FIRE HAZARD.

## FRAME-IN KIT INSTALLATION: See frame-in kit instruction sheet for installation procedure.

### **ATTACH SOCKET CUP TO TRIM:**

2a. Socket cup is attached to trims by use of socket cup spring channels on inside of eyeball.



2b. Align one socket cup spring leg with the channel on



2c. Squeeze socket cup spring legs together and insert the second leg into the channel on the opposite side of eyeball.



2d. Push socket cup into eyeball until both socket cup spring legs hit the tab at the base of the channel.

**NOTE:** Spring tension should draw socket cup into position.







### **PUSH UP:**

Pre-aim and push trim straight up into fixture housing until it is tight against the ceiling.

Aiming may be adjusted as necessary. For rotational adjustment remove trim from fixture housing and reposition to achieve the desired aiming.





LIGHTOLIER A GENLYTETHOMAS COMPANY 631 Airport Road, Fall River, MA 02720