INSTALLATION INSTRUCTIONS FOR VETRO SERIES

Read and understand these instructions before installing luminaire.

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.


Retain these instructions for maintenance reference.

Note: This instruction sheet covers several luminaire types and styles. Although the illustration may not depict the product exactly, the installation remains the same.

Outer Glass Installation:

- 1) Unscrew UPPER BODY from LOWER COLLAR (fig. 1).
- 2) Insert OUTER GLASS SUPPORT RING onto LOWER COLLAR. Screw LOWER COLLAR to UPPER BODY and fully tighten.
- 3) Slide OUTER GLASS up around UPPER BODY until holes in OUTER GLASS line up with holes in OUTER GLASS SUPPORT RING. Insert one OUTER GLASS SUPPORT PIN though hole in OUTER GLASS and screw into OUTER GLASS SUPPORT RING, repeat for remaining OUTER GLASS SUPPORT PINS. Make certain OUTER GLASS SUPPORT PINS are screwed in tightly.

CAUTION: MAXIMUM WATTAGE AS MARKED ON LUMINAIRE MUST NOT BE EXCEEDED



Lightolier a Genlyte Group Company www.lightolier.com 631 Airport Road, Fall River, Ma 02720 (508) 679-8131 Fax (508) 674-4710 We reserve the right to change details of design, materials and finish. • ©2006 Genlyte Thomas Group LLC•A0403