# **Chopstick** WALL LED

# Installation Instructions

ID-7508\_ChopstickLED\_wall



#### **System Overview**

These instructions review how to install Chopstick LED wall mount fixtures. Chopstick 4ft, 6ft, & 8ft modules can be installed as individual standalone units, or they can be joined together to create continuous rows. The graphic below shows the components required to install a typical row of Chopstick LED wall mount fixtures.



## Module Lengths

Chopstick LED wall mount systems come in 4ft, 6ft, and 8ft modules. Overall module lengths are shown below. Module lengths do not include endcaps.



#### Endcaps

Add two endcaps to the length of each row.



## Mount Spacing

- Mounts variable within 2" 5" to end of joint. On 8ft module, additional mount to be located within 2"- 5" of fixture centerline.
- Side-mounted 2"x4" J-box (supplied by others)

## **Row Configurations**

The table below indicates how 4ft, 6ft, & 8ft modules can be combined to create continuous rows of various lengths.

Nominal row length	4'	6'	8'
4'	lx		
6'		lx	
8'			١x
10'	١x	lx	
12'	١x		١x
14'		lx	١x
16'			2x
18'	lx	lx	١x
20'	١x		2x

ATTENTION: Install in accordance with national and local building and electrical codes.

Page I

# Chopstick WALL LED

# Installation Instructions

ID-7508\_ChopstickLED\_wall



Determine power feed location and install 2"x4" J-box (supplied by others) parallel with the fixture. Complete connections at J-box with supplied power cord. On supplied J-box cover plate, feed power cord through rectangular hole. Secure cover to wall and J-box using applicable hardware (supplied by others).



**RECOMMENDED:** Feed power cord through top of wall bracket and attach to J-box cover with 2 screws (supplied). Leave power cord outside wall for connection.

**ALTERNATE:** Install wall bracket within 2-5" from fixture end, as close as possible to power supply. Secure bracket to wall structure.



## Standalone or continuous run configurations

Install wall bracket at nonpower locations



Install additional wall brackets as required for single fixture or continuous rows. Ensure additional brackets are level with first bracket.

**IMPORTANT:** Attach wall brackets to wall structure within 2-5" from ends of fixture.

**For 8ft fixture:** Attach an additional bracket within 2-5" from the centerline of the 8ft fixture

# 4

Arrange boxed fixtures on floor in specified mounting locations, remove fixtures from boxes.

**IMPORTANT:** All mount brackets must be secured to wall structure

(e.g studs or cross-braces).

**NOTE:** If conditions are dusty/dirty, recommended practice is to leave fixtures in their plastic bag. Cut small holes in bag as needed to complete the following installation sequence, and then completely remove the bag from the fixture when conditions are clean.



Remove TOP REFLECTOR by sliding to one side then lifting off.





Install required number of rail brackets, per steps 2-3, on the housing. Slide along the length of housing to approximate location matching the brackets on the wall.

Revision 1.0

## ATTENTION: Install in accordance with national and local building and electrical codes.

© 2016 Philips Lighting Holding B.V. All rights reserved Phone: 604.888.6811 Web: philips.com/luminaires

# Chopstick

# Installation Instructions

WALL LED

## ID-7508 ChopstickLED wall

hardware.





With 2 people, raise fixture into position and engage it on hooks located on top of wall brackets. Secure bracket using supplied hardware.

**POWER LOCATIONS:** Feed installed power cord through the access slot at the top of the rail bracket.



Slide spring clips onto existing wall mounted fixture.



With two people, raise second fixture to wall. At joint, insert joiner aligners through black GASKET and into wall mounted fixture. At other end of joining fixture, install wall bracket as in step 7.

**IMPORTANT:** Do not attempt to join fixtures on floor. Correct method is to hang one fixture at a time and join fixtures at ceiling level.

## Standalone or continuous run configurations



**POWER LOCATIONS:** Break required 1/2" round knockout(s) in wire cover. Insert supplied bushing into  $\frac{1}{2}$ " round hole. Feed power cable through 1/2" bushing and into wire cavity. Apply supplied strain relief to power cord. Remove installed quick wire connectors (if applicable) and complete electrical connections using wire nuts (supplied by others). Tuck wires into wire cavity.



PHILIPS

For each additional fixture in the row, at the end where it will join to the existing wall mounted fixture, insert joiner aligners into the crossplate (aligners will lock into place).



NON-POWER LOCATIONS: Use supplied quick-wire connectors. Tuck wires into wire cavity.

POWER LOCATIONS: Remove installed quick-wire connectors and complete electrical connections using wire nuts (supplied by others). Tuck wires into wiring cavity.



Slide second fixture flush against first fixture. Secure joint using supplied hardware. Secure and level fixture to wall bracket as in step 7. For additional fixtures, repeat steps 9-12.

ATTENTION: Install in accordance with national and local building and electrical codes.

© 2016 Philips Lighting Holding B.V. All rights reserved Phone: 604.888.6811 Web: philips.com/luminaires Page 3

# Chopstick

# Installation Instructions

WALL LED

ID-7508 ChopstickLED wall







Attach endcap to first and last module in each row using supplied hardware. Use the two endcap studs shown in above image.

**IMPORTANT:** Do not over-tighten endcap hardware. Tighten by hand. When nut is flush with crossplate, turn additional 1/8 –1/4 turn.

## Install LIGHTGUIDE PANEL



Locate LIGHTGUIDE panel in fixture box, peel protective layer from both sides of panel, and install SHINY SIDE DOWN in fixture as shown.

**IMPORTANT: INSTALL SHINY SIDE** DOWN





I. Re-install top reflector from step 5.

2. Shift into place.

## ATTENTION: Install in accordance with national and local building and electrical codes.

Page 4