

# FLOODPAK



## INSTALLATION INSTRUCTIONS

Size 1, 2 and 3

This fixture must be installed by a qualified electrician

### Wall-Mounting The Floodpak

1. Using matrix "Fig1 ①" Select desired fixture orientation.
2. Using matrix "Fig1 ②" locate required gasket position and apply gasket to housing.
3. Using matrix "Fig1 ③" locate required Mount Box orientation.

Fig 1		①	②	Gasket Position
Fixture Orientation		<p>0° Down / Cutoff</p>	<p>0° UP</p>	
		<p>22° Down/Semi-Cutoff</p>	<p>22° UP</p>	
		<p>45° UP</p>	<p>45° Down / Flood</p>	
③		<p>Upright</p>	<p>Upside down</p>	
		Mount Box Orientation		

**NOTICE:** Fixture is listed under UL Standard #1598, for wet locations. It is not intended for use in car washes, hose down areas, or in direct contact with lawn sprinklers or roof runoff. In addition, this fixture should not be mounted in elevated ambient areas or areas that may entrap heat (i.e.- indoor pools, saunas, etc.).