

Decoflood

MVF616 Range

Mounting instruction 安装说明

4441 000 63262



ta
35°

IP65



IEC
60598






GB
7000



0.104m²



Product Name 产品名称	Lamp 光源	Reflect 反射器	V/Hz 电压/频率	Lampholder 灯座	
MVF616	SON-T70W	MB/ WB	220V/50Hz	E27	6.3
	SON-T100W	MB/ WB	220V/50Hz	E40	7.3
	SON-T150W	MB/ WB	220V/50Hz	E40	7.6
	MHN-TD70W	MB/ WB	220V/50Hz	Rx7S	6.4
	MHN-TD150W	MB/ WB	220V/50Hz	Rx7S	7.1
	SDW-T100W	MB/ WB	220V/50Hz	PG12-1	7.1



The burning position of horizontal for MHN-TD70W/150W should be allowed $\pm 45^\circ$
光源MHN-TD70W/150W在水平位置的点燃允许角度 $\pm 45^\circ$



1. If the front glass is broken, switch off the main supply and replace the front glass.
切断电源，更换玻璃。
2. Disconnect the unit before changing the lamp.
更换灯泡前，请先切断电源。
3. Do not cover the luminaire with combustible.
灯具不允许被可燃物覆盖。

Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huyi Road, Jiading, Shanghai, China
Postalcode: 201801

飞利浦灯具（上海）有限公司
地址：中国上海市嘉定区马陆镇沪宜公路2688号
邮编：201801

PHILIPS

