

Philips Lighting

Installation instructions

Instructions de montage
Montageanweisung
Montagevoorschrift

Istruzioni di montaggio
Instrucciones de montaje
Monteringsanvisning


SNF 111

Windage area
Surface au vent
Luftwiderstand
Windvangend oppervlak
Superficie al vento
Superficie expuesta al viento
Vindfångstyta



$A = 0.19 \text{ m}^2$

Weight
Poids
Gewicht
Gewicht
Peso
Peso
Vikt

23.5 kg



1 x SON-T 1000 W
1 x HPI-T 1000 W
2 x SON-T 400 W
2 x HPI-T 400 W



If the front glass is broken, switch off the luminaire and replace the front glass.

En cas de rupture de la vasque, la remplacer après avoir mis le luminaire hors circuit.

Sollte die Glasscheibe brechen, ist die Leuchte auszuschalten und die Glasscheibe zu ersetzen.

In geval van ruitbreuk het armatuur uitschakelen en de ruit vervangen.

In caso di rottura del paralume, disinserire l'armatura e sostituirlo.

Si se rompe el cristal, desconecte la armadura y sustitúyalo.

Om frontglaset är spräckt, stäng av lampan och byt ut frontglaset.

Attention

Switch off the mains voltage before opening the floodlight.

Attention

Couper la tension avant d'ouvrir le luminaire.

Warnung

Die Leuchte nur öffnen, wenn die Netzspannung ausgeschaltet ist.

Atentie

Open het armatuur niet voordat de netspanning is uitgeschakeld.

Attenzione


Prima di aprire il proiettore, togliere corrente.

Atención

Desconecte la tensión de la red antes de abrir la armadura de la lámpara.

Viktigt

Slå av nätspanningen innan strålkastaren öppnas.



Minimum distance to any combustible material.

Distance minimale jusqu'aux surfaces pouvant prendre feu.

Minimaler Abstand zu brennbaren Gegenständen.

Minimale afstand tot brandbare oppervlakten.

Distanza minima rispetto a superfici infiammabili.

Separación mínima hasta superficies inflamables.



Minsta avstånd till belyst föremål.

Philips Lighting





PHILIPS

1








2a

SON/T
HPI/T
1000 W




2b


SON/T
HPI/T
2 x 400 W




3




4a



4b



5





PHILIPS