

SAVIO Office lighting/ 办公照明灯具

TCS760/TPS760/TPS762

Mounting instruction 安装说明



IP20



ta
25°

Type 产品型号	Lamp 光源	Vol./ Fre. 电压/频率	Mounting Mode 安装方式	
TCS760/228	2xTL5 HE 28W	220-240V~/ 50/60Hz	Ceiling mounting/ 吸顶安装	9.0
TCS760/235	2xTL5 HE 35W			10.2
TCS760/249	2xTL5 HO 49W			10.2
TCS760/254	2xTL5 HO 54W			9.0
TCS760/414	2xTL5 HE 14W			8.0
TPS760/228	2xTL5 HE 28W	220-240V~/ 50/60Hz	Suspending mounting/ 悬吊安装	9.0
TPS760/235	2xTL5 HE 35W			10.2
TPS760/249	2xTL5 HO 49W			10.2
TPS760/254	2xTL5 HO 54W			9.0
TPS760/414	2xTL5 HE 14W			8.0
TPS762/228	2xTL5 HE 28W	220-240V~/ 50/60Hz	Suspending mounting/ 悬吊安装	9.0
TPS762/235	2xTL5 HE 35W			10.2
TPS762/249	2xTL5 HO 49W			10.2
TPS762/254	2xTL5 HO 54W			9.0
TPS762/414	2xTL5 HE 14W			8.0


- Suffix "ACL" in the type desc. means the luminaire assemble a Actilume Dali lighting control systems.

型号描述后带"ACL"表示该灯具带有 Actilume Dali 调光控制器。


- Suffix "LX" in the type desc. means the luminaire assemble a Luxsense I-10V lighting control systems.

型号描述后带"LX"表示该灯具带有 Luxsense I-10V 调光控制器。


TCS760 228/235/249/254




TCS760 414



TPS760/TPS762 228/235/249/254



TPS760/TPS762 414






For indoor use only
仅限室内使用

Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huyi Road, Jiading, Shanghai, China
Postalcode: 201801





飞利浦灯具(上海)有限公司
地址: 中国上海市嘉定区马陆镇沪宜公路2688号
邮编: 201801

PHILIPS





TCS760



TPS760/ 762



Lamp replacement/ 更换光源



- During installation or maintaining the luminaire please use gloves to avoid spots on the cover.
安装及维护过程中, 请使用手套以免弄脏透光罩。
- Always ensure that in square luminaire configuration the lamp-positions are in the planned direction. In case of re-lamping, please carefully follow instructions in the luminaire, and place all lamps in one direction in case of the cold spot (the branded side).
请确认光源位置在方形灯具里面是预先设定的方向。更换光源时, 请仔细阅读使用说明书, 将所有光源按同一方向放置。
- Remove the protection foil on the cover only short before usage of the lighting installation.
请在灯具安装好准备调试使用时再拿掉透光罩表面的保护膜。

- After installation, the luminaire with colour variation needs to burn-in 100 hours to reach its stable colour and flux performance.
可调光灯具安装好后, 约需要点灯100小时后才能达到稳定的光色和光输出。
- It's not recommended to use other lamps than the Philips lamps.
不推荐使用飞利浦品牌之外的光源。
- The luminaire shall be installed by a qualified electrician according to specified step, and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工按照说明书中所示步骤进行安装, 接线要符合IEE电气标准或国家标准。
- The luminaire suit for IEC60598.1, IEC60598.2.1, EN55015, EN61547, EN61000-3.
灯具符合国标GB7000.1, GB7000.201, GB17743, GB17625。

Please turn off the power supply before the lamp replacement.
更换光源前请务必先关闭电源。