

INSTALLATION INSTRUCTIONS

FLUORESCENT HIGHBAY "FBF" SERIES

CAUTION: THE INSTALLATION AND SERVICING OF THIS PRODUCT SHOULD BE PERFORMED BY A QUALIFIED ELECTRICIAN OR SERVICE PERSONNEL
ATTENTION : L'INSTALLATION ET L'ENTRETIEN DE CE PRODUIT DOIVENT ÊTRE EFFECTUÉS PAR UN ÉLECTRICIEN OU UN MEMBRE DU PERSONNEL QUALIFIÉ.

- 1). Remove unit from carton and inspect to insure no shipping damage has occurred.
- 2). This luminaire is supplied with an access plate for wiring access.
- 3). To install with optional chain/hanger kit (MUST BE ORDERED SEPARATELY): Remove the V-Hook and chains from the bag pack. Hook the V-Hook into each end of the luminaire in the holes located at each end. The chains should then be attached to the permanent structure of the building. (See Figure 1)






FIG.1 - INSTALLATION WITH OPTIONAL CHAIN HANGER (MUST BE ORDERED SEPARATELY)



- 4). An access plate location has been provided for wiring entrance. If ballast and wiring must be accessed directly, remove lamps and reflector as shown. (See Figure 2 & 3)
- 5). All Luminaires have rectangular uplight slots on in the back of the housing. Luminaires with the uplight option ("U" in the catalog number or options) also have slots in the reflectors that are aligned with the slots in the housing at the factory. To convert to no uplight, remove the reflectors and rotate them 180 degrees so the slots in the reflectors do not match the slots in the housing. Re-install the reflectors. (See Figure 4)




FIG. 4

CAUTION: Electrical luminaires are designed for permanent installation in ordinary (Non-Hazardous) locations in accordance with the National Electrical Code and all applicable local codes. Do not use in areas of limited ventilation or in high ambient enclosures. The lamp and luminaire operate at high temperatures, contact with combustible materials can cause fire and personal contact can cause severe burns.

ATTENTION: Ce luminaire a été conçu pour une installation permanente dans un emplacement régulier (non dangereux) et en conformité avec le Code électrique canadien et codes locaux applicables. Ne jamais installer dans un endroit où la ventilation est limitée ou dans des boîtiers où la température ambiante est très élevée. La lampe et le luminaire fonctionnent à des températures élevées, un contact avec des matériaux combustibles peut engendrer un incendie et un contact corporel peut causer de sévères brûlures.

PHILIPS

Philips Lighting North
America Corporation
200 Franklin Square Drive
Somerset, NJ 08873, USA
Phone: 855-486-2216
philips.com/luminaires

Philips Lighting Canada Ltd.
281 Hillmount Road
Markham ON, Canada L6C 2S3
Phone: 800-668-9008
philips.com/luminaires

717876103 APRIL, 2013
12NC: 443580048420