

TBS 528 Opal & P6



Installation instruction

安装说明


A




Type NO. 型号	Length 长 (mm)	Width 宽 (mm)	High 高 (mm)	Weight 重 (kg)	Lamp 光源	Lamp Holder 灯座	Gear 电器	Optics 反射器
TBS528 P 2×TL5-14W	597	297	76	3.0	2×TL5-14W	G5	HFP HFS FBA ELB	P6 Opal
TBS528 P 3×TL5-14W	597	597	76	5.1	3×TL5-14W	G5		
TBS528 P 4×TL5-14W	597	597	76	5.1	4×TL5-14W	G5		
TBS528 P 2×TL5-28W	1197	297	76	5.4	2×TL5-28W	G5		
TBS528 P 3×TL5-28W	1197	597	76	8.2	3×TL5-28W	G5		
TBS528 P 2×TL5-35W	1497	297	76	6.4	2×TL5-35W	G5		




Suspension via hooks 钩式悬挂安装





1 Housing installation 灯具安装





2 Supply cable installation 连接电源线



3 Lamp & Louver installation 安装灯管和格栅



Hanging via bracket 支架安装



Rest steps same as suspension mounting 其余步骤同悬挂安装方式相同



- 1、 The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工安装，接线要符合IEE 电气标准或国家标准。
- 2、 The luminaire shall ,under no circumstance,be covered with insulation matting or similar material.
灯具不适合被隔热或类似材料覆盖。




TBS528/235 869/235

Mounting instruction






安装说明



Type 型号	Cut out 开孔尺寸	Weight 重	Lamp 光源	Lampholder 灯座	Gear 电器	Optical 反射器
TBS869/235/8 TBS528/235/2 TBS528/235/8	2×TL5-35W 1480×280mm	4.3kg	2×TL5-35W	G5	HFP HFS FBA ELB	D8 D8-H C8-H M2 M8



Suspension via hooks or rods 钩式或吊杆悬挂安装




1、The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.

灯具应由有资格的电工安装，接线要符合IEE 电气标准或国家标准。


2、The luminaire shall ,under no circumstance,be covered with insulation matting or similar material.

灯具不适合被隔热或类似材料覆盖。


1 Housing installation 灯具安装




2 Supply cable installation 连接电源线




3 Lamp installation 安装灯管



4 Louver installation 安装格栅



Hanging via bracket 支架安装



Rest steps same as suspension mounting 其余步骤同悬挂安装方式相同