




ATTENTION!



DayZone Lighting Technology

Maintenance instructions

Given the choices made in this unique lighting concept, there are a few instructions regarding the maintenance of this luminaire to assure the lighting qualities:

☐ During installation or maintaining the luminaire please use gloves to avoid spots on the cover.

☐ Dirty spots can be removed:

- Only dust: with micro fiber cloth
- Fingerprints, etc.: with a cleaner for synthetic material with antistatic effect.

☐ Remove the protection foil on the cover only short before usage of the lighting installation.

☐ Do not touch electronic components! ESD sensitive.

☐ Do not stare into LED beam.


☐ DayZone luminaires with dali driver also support touch & dim functionality. For wiring schemes please visit www.dimming.philips.com and go to technical notes.

ATTENTION!



NOTE:
Don't use plastic gloves.

Advice:
two people for mounting



DayZone BBS56I

Installation instructions

Instructions de montage
Montageanleitung
Montage instructie
Istruzioni di montaggio

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergeleri
Οδηγίες συναρμολόγησης
Instrukcja montażu



Szerelési utasítások
Návod k montáži
ИНСТРУКЦИЯ ПО МОНТАЖУ
Návod k montáži

IP 40

This luminaire must be earthed.
Ce luminaire doit être mis à la terre.
Diese Leuchte muß geerdet werden.
Dit armatuur moet worden geaard.
Questa armatura deve essere collegata a terra.
La Luminaria debe estar conectada a tierra.








Class I




BBS56I 6.6 kg


ZBS460 SMB-PLC




Wieland (W) PSD




Wieland 4 (W4) PSD EL




WAGO (WA) PSD




WAGO 4 (WA4) PSD EL



ENSTO (EN) PSD



PSD



Push-In (PI) PSD

