

Elite HighBay 高天棚灯具

HPK518c

Mounting instruction / 安装说明书

MPK518-M001a




Type Description 型号描述	Vol./Fre. 电压/频率		
MPK518/CDM210W/WB MPK518/CDM210W/NB	220-240V~ 50/60Hz	Master Colour Elite CDM-TMW 210W PGZ18	9.5 Kg
MPK518/CDM315W/WB MPK518/CDM315W/NB		Master Colour Elite CDM-TMW 315W PGZ18	9.5 Kg


Accessories/附件:

1. GDK518: Aluminium reflector (necessary)
2. ZPK518 GC: glass cover (necessary)
3. Mounting hook: for optional



Dimensions尺寸 (Unit:mm)



Installation安装应用



Installation安装应用



Maintenance维护保养

1、In order to ensure optimum performance, please clean the luminaire regularly (recommended twice a year). While cleaning the luminaire, please use a soft cotton pad only.
为了保持灯具明亮效果, 请定期 (半年一次) 进行清洁。灯具清洁时请使用软布擦拭。

2、Please turn off the power before maintenance and lamp replacement.
须断开电源后, 才能维修和更换光源。

3、The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工安装, 接线要符合IEE电气标准或国家标准。

4、Please replace any cracked safety screen.
钢化玻璃保护屏碎裂时请立即更换。

5、This luminaire is not suitable for the corrosive environment and area prone to hurricane and extreme winds.
本灯具不适合安装在会产生酸性碱性腐蚀的环境及海边、港口等强台风多发地区。

6、The luminaire suit for IEC60598.2.1, IEC60598.1, EN55015, EN61547
灯具符合国标GB7000.201, GB7000.1, GB17743, GB17625

7、The gear unit must be used with corresponding reflector/glass sets. Philips will not be responsible for all consequences if misused.
本产品之电器箱必须与对应的反射器/玻璃组件配套使用, 飞利浦不承担因搭配使用不当而产生的一切后果及责任。