

Maxos Warehouse System

Installation instructions

Instructions de montage

Montageanleitung

Montage instructic

Istruzioni di montaggio

Instrucciones de montaje

Instrues de montage

Monteringsinstruktioner

Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet

Montaj yönergesi

Οδηγίες εγκατάστασης

Instrukcja montazu

Szerelési utasítások

Návod k montázi

инструкция по монтажу

Návod k montázi



CLI



IP20


220 V
240 V

CE0682



12NC	Designation	Qty of Lighting unit	Qty of Blind unit	Qty of Control unit	Retrofit length type	System length	Trunking system
910500456556	LL850X G2 4LL 3BC 498 LED66S/840 NB ACW	4	3	1	8x (49W T5)	~12 m (8x 1476 mm)	Maxos
910500456557	LL850X G2 4LL 3BC 588 LED66S/840 NB ACW	4	3	1	8x (58W TLD)	~12 m (8x 1527 mm)	Maxos
910500456558	LL400X G2 4LL 3BC 498 LED66S/840 NB ACW	4	3	1	8x (49W T5)	~12 m (8x 1476 mm)	TTX400
910500456559	LL400X G2 4LL 3BC 588 LED66S/840 NB ACW	4	3	1	8x (58W TLD)	~12 m (8x 1527 mm)	TTX400
910500456560	LL850X G2 3LL 2BC 496 LED66S/840 NB ACW	3	2	1	6x (49W T5)	~8 m (6x 1476 mm)	Maxos
910500456561	LL850X G2 3LL 2BC 586 LED66S/840 NB ACW	3	2	1	6x (58W TLD)	~8 m (6x 1527 mm)	Maxos
910500456562	LL400X G2 3LL 2BC 496 LED66S/840 NB ACW	3	2	1	6x (49W T5)	~8 m (6x 1476 mm)	TTX400
910500456563	LL400X G2 3LL 2BC 586 LED66S/840 NB ACW	3	2	1	6x (58W TLD)	~8 m (6x 1527 mm)	TTX400

Lighting plan examples per one kit:



1.

444316005011

Version date 22/05/2014

Data Subject to change without notice



Printed in EU

www.philips.com/lighting

PHILIPS


Control unit

Fixing in the trunk:
Rotate the 2 locks




Blind unit



Fixing in the trunk:
Snap in to the trunk



Lighting unit


Fixing in the trunk:
See on next pages






Installation of the units

4MX850 Ligting unit



Installation of the units

4MX400 Lighting unit



Warehouse System (WHS)

Installation instructions

Instructions de montage




Montageanleitung

Montage instructie



Istruzioni di montaggio

Instrukcje instalacji



Instrucciones de montaje




You must have a lighting plan, if you install the WHS.



Do not install the WHS control unit close to steel or concrete constructions.




Do not block the view of the WHS sensor.




Apply a cover to the sensor, if empty places occur in the warehouse. The cover will prevent motion detection in the adjacent corridor through the empty places.

PHILIPS




Installation

- 1 Put the flying lead (a) in the fixed connector (b)
- 2 Push the connected side of the luminaire in the trunking line.
- 3 Push the other side of the luminaire in the trunking line.




CAUTION

You must start with the side that has the flying lead (a).



CAUTION

Don't connect the last blind plate, before you continue with a new kit.



RH

20 - 85%

IP20



2.2 kg

