

4422 003 64422
02/10
Printed in the Netherlands
Data subject to change

SmartForm TWS 462

Installation instructions

Instructions de montage	Instrucciones de montaje	Kokoonpano- ja kiinnitysohjeet	Szerelési utasítások
Montageanleitung	Instruções de montagem	Montaj yönergeleri	Návod k montáži
Montage instructie	Monteringsinstructie	Οδηγίες συναρμολόγησης	ИНСТРУКЦИЯ ПО МОНТАЖУ
Istruzioni di montaggio	Monteringsvejledning	Instrukcja montażu	Návod k montáži

IP 20 - IP 40

This luminaire must be earthed.
Ce luminaire doit être mis à la terre.
Diese Leuchte muß geerdet werden.



Dit armatuur moet worden geaard.
Questa armatura deve essere collegata a terra.
La Luminaria debe estar conectada a tierra.

Class I




All dimensions are in mm.

Power (W)	L	W	A	C
13/14/20/24 W	640	135	49	585
25/28/50/54 W	1240	135	49	1185




Wall Side


HFP / HFPi



HFD-T








HFR / HFD



Use Philips lamps for optimum performance
Funzionamento ottimale garantito con lampade Philips
Resultados óptimos con lámparas Philips
Toimii parhaiten Philips-lamppujen kanssa
Funciona melhor com lâmpadas Philips no interior
Werkt het best met Philips-lampen

Fonctionnement optimal avec lampes Philips
Bestes Betriebsergebnis mit Philips-Lampen
Fungerer bedst med Philips-lamper
Fungerer mest optimalt med Philips-lamper
Fungerar bäst med lampor från Philips



cover remover (ZZS400 OCR)

