



TBS528/869

Mounting instruction 安装说明


TBS869-M001a



Type Number 产品型号		Length 长 (mm)	Width 宽 (mm)	High 高 (mm)	Cut out 开孔尺寸 (mm)	Weight 重量 (kg)	Lamp 光源	Lampholder 灯座	Gear 电器	Optical 反射器
TBS528 TBS869	214	595	295	47	580×280	2	TL5-14W	G5	ELB	M2
	314	595	595	47	580×580	4.2	TL5-14W		EBE	M8
	414	595	595	47	580×580	3.9	TL5-14W		EBS	M8-H
	128	1195	145	100	1180×130	2	TL5-28W		EBP	D8
	128/WV	1195	295	47	1180×280	3.2	TL5-28W		HFA	D8-H
	228	1195	295	47	1180×280	3.2	TL5-28W		HFD	C8
	228/WV	1195	595	47	1180×580	6.2	TL5-28W		HFR	C8-H
	328	1195	595	47	1180×580	6.3	TL5-28W			





Suspension via hooks or rods 钩式或吊杆悬挂安装




- The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工安装，接线要符合IEE电气标准或国家标准。
- The luminaire shall, under no circumstance, be covered with thermal insulation matting or similar material.
灯具不能被隔热或类似材料覆盖。



1 Housing installation 灯具安装




2 Supply cable installation 连接电源线







3×1mm² - 1.5 mm²







3 Lamp installation 安装灯管



4 Louver installation 安装格栅



Hanging via bracket 支架安装



Rest steps same as suspension mounting
其余步骤同悬挂安装方式相同