


Unicone Projector

Installation Instruction 安装说明

MRS553 - M002a



M-  L- 	Lamp 光源	A Ø	B mm		
MRS553/ MCS553	CDM-R11135-70W	129	224(3C)	1.3	1.2
LRS553/ LCS553	HAL-R111-60W	129	204(BA)	1.2	1.2



Disconnect the unit before changing the lamp.
更换光源前要断开电源。



Hot! Do not change bulb or adjust lighting position until cooling down.
烫! 更换光源或调整灯具时, 务必在熄灯冷却后进行。



The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
Class II luminaires should use a supplementary insulation or double insulation supply cable.
Luminaires provides with metal halide lamps: the luminaires shall only be used complete with its protective shield.
灯具应由有资格的电工安装, 接线要符合IEE电气标准或国家标准。
II类灯具请用附加绝缘或者双重绝缘电源线连接。
金卤灯具: 灯具应只能完整地带有保护屏使用。

