

TPS498

Mounting instruction 安装说明

TPS498 - M001a




IEC
60598




GB
7000



Housing/ Type 功率/型号	Length B 长度(mm)	Suspension A 悬吊间距(mm)
36W (TL-D)	1338	1240
58W (TL-D)	1638	1540
28/54W (TL-5)	1286	1188
35/49W (TL-5)	1586	1488






Indoor use only
仅限室内使用




Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huyi Road, Jiading, Shanghai, China
Postalcode: 201801
飞利浦灯具(上海)有限公司
地址: 中国上海市嘉定区马陆镇沪宜公路2688号
邮编: 201801





PHILIPS



ZPH498 CP



Housing (Type) 功率/型号	Suspension C 悬吊间距 (mm)	Suspension D 悬吊间距 (mm)
36W (TL-D)	1260	1280
58W (TL-D)	1560	1580
28/54W (TL-5)	1208	1288
35/49W (TL-5)	1508	1528



1. The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工安装，接线要符合IEE电气标准或国家标准。
2. Please shut off power supply before changing lamp.
更换光源时请切断电源。