


SCRABBLE



MBX500/CBX500

Installation Instruction 安装说明

MBX500-M001a




Product Type	Product Family Code	Product Dimension(mm) L×W×H	 (mm)	Lamp Holder	Lamp	Color		
MBX500 1×CDM-R30-70W IC WH	MBX500	185×185×175	167×167	E27	CDM-R30 70W/830	White	3.2	
MBX500 2×CDM-R30-70W IC WH		327×185×175	308×167				6.0	
MBX500 3×CDM-R30-70W IC WH		469×185×175	450×167				8.8	
MBX500 1×CDM-R30-35W IC WH		185×185×175	167×167		CDM-R30 35W/830		2.8	
MBX500 2×CDM-R30-35W IC WH		327×185×175	308×167				5.2	
MBX500 3×CDM-R30-35W IC WH		469×185×175	450×167				7.6	
MBX500 1×CDM-R30-70W IC SI		185×185×175	167×167		CDM-R30 70W/830	Silver	3.2	
MBX500 2×CDM-R30-70W IC SI		327×185×175	308×167				6.0	
MBX500 3×CDM-R30-70W IC SI		469×185×175	450×167				8.8	
MBX500 1×CDM-R30-35W IC SI		185×185×175	167×167		CDM-R30 35W/830		2.8	
MBX500 2×CDM-R30-35W IC SI		327×185×175	308×167				5.2	
MBX500 3×CDM-R30-35W IC SI		469×185×175	450×167				7.6	
MBX500 1×CDM-R20-35W IC WH		148×148×152	130×130		CDM-R20 35W/830	White	2.6	
MBX500 2×CDM-R20-35W IC WH		258×148×152	240×130				4.8	
MBX500 3×CDM-R20-35W IC WH		368×148×152	350×130				7.2	
MBX500 1×CDM-R20-35W IC SI		148×148×152	130×130			Silver	2.6	
MBX500 2×CDM-R20-35W IC SI		258×148×152	240×130				4.8	
MBX500 3×CDM-R20-35W IC SI		368×148×152	350×130				7.2	
CBX500 1×CDM-R30-70W 1×HAL-R111 50W WH	CBX500	327×185×175	308×167	E27 + G53	CDM-R30 70W/830 + HAL-R 111 MAX50W	White	4.5	
CBX500 1×CDM-R30-70W 2×HAL-R111 50W WH		469×185×175	450×167				5.6	



Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huiyi Road, Jiading, Shanghai, China
Postalcode: 201801
飞利浦灯具（上海）有限公司
地址：中国上海市嘉定区马陆镇沪宜公路2688号
邮编：201801

PHILIPS



1. The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.

灯具应由有资格的电工安装，接线要符合IEE 电气标准或国家标准。

2. The luminaire shall, under no circumstance, be covered with thermal insulation matting or similar material.

灯具不适合被隔热或类似材料覆盖。

3. Please don't use the luminaire together with a dimming device, electronic switch or remote control.

本灯具不与调光器、电子开关、远程遥控器连接使用。

