

Arano TCS640

Installation instruction/安装说明

TCS640-M-00a




IP20




CB


ta
25°



	A	C
	mm	mm
28/54W	1252	1000
35/49/54W	1552	1300





I



Fix suspension brackets onto ceiling
把悬吊支架固定于天花板上


2

Open wire cover
打开接线盖




3

Suspend luminaire by plastic rope attached on bracket
利用支架上的安装塑绳把灯体悬吊于空中





4

Connect power wire (Keep right pole connection)
接线（注意不要接错电极）





5

Install wire cover back
装回接线盖



6


Hang luminaire by suspension
brackets
把灯挂于安装支架上



7

Press v clip to uninstall louver, install
lamp, then install louver back. Gloves
must be used when touching louver.
按下V形卡扣，拆下格栅或天窗，安
装光源，最后装回格栅或天窗。触
碰格栅时必须使用手套。

Service



This luminaire series should be installed by qualified electrical workers, wire connection should comply with latest IEE and related national standard.

本灯具系列应由有资质的电工安装，接线须遵守最新IEE和相关国家标准。



Please be aware of power must be cut off before you replace the lamp.

更换光源之前请务必切断电源。

Indoor use only!

仅限室内使用！