

**INSTALLATION INSTRUCTIONS FOR VETRO SERIES****Read and understand these instructions before installing luminaire.**


This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

**Note:** This instruction sheet covers several luminaire types and styles. Although the illustration may not depict the product exactly, the installation remains the same.

**Installation For SK Series:**

- 1) Insert 1/4-20 STUD and attach GROUND SUPPLY LEAD to CROSSBAR (fig. 1).
- 2) Screw CROSSBAR to 4" octagonal j-box (fig. 2).
- 3) Bring CANOPY to j-box and make electrical connections: Connect BLACK LUMINAIRE LEAD to HOT (BLACK) SUPPLY LEAD; WHITE LUMINAIRE LEAD to NEUTRAL (WHITE) SUPPLY LEAD; GROUND LUMINAIRE LEAD (COPPER) must be connected to the GROUND SUPPLY LEAD. Use wire nuts supplied to make connections. Push connections back up into j- box (fig. 2).
- 4) Pass CANOPY onto 1/4-20 STUD and screw AIRCRAFT CABLE ASSEMBLY onto 1/4-20 STUD and tighten flush to ceiling, making sure wires and connections are not pinched.
- 5) Mount luminaire: For luminaire installation see instruction sheet supplied with luminaire.
- 6) Once luminaire is installed add CABLE CLIPS (3X). First slide AIRCRAFT CABLE into CABLE CLIP then POWER CORD. When the CABLE CLIPS are in the desired position lightly crimp the CABLE CLIP to POWER CORD with a SMOOTH JAW PLIER so not to mar finish of the CABLE CLIP (fig. 3).



**CAUTION:** MAXIMUM WATTAGE AS MARKED ON LUMINAIRE MUST NOT BE EXCEEDED

