


TBS 707

Mounting instruction 安装说明

TBS707-M001a




Type NO. 型号	Length 长 (mm)	Width 宽 (mm)	High 高 (mm)	Weight 重量 (kg)	Lamp 光源	Lamp Holder 灯座	Gear 电器	Optics 反射器
TBS707 3×TL5-14W	597	597	101	5.4	3×TL5-14W	G5	EB	D6
TBS707 2×TL5-28W	1197	297	101	5.5	2×TL5-28W	G5		M6
TBS707 3×TL5-28W	1197	597	101	9	3×TL5-28W	G5		IND




Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huyi Road, Jiading, Shanghai, China
Postalcode: 201801
飞利浦灯具（上海）有限公司
地址：中国上海市嘉定区马陆镇沪宜公路
邮编：201801

PHILIPS


Suspension via hooks 钩式安装




1 Housing installation 灯具安装




2 Connect entry cable 连接电源线





3 Gear cover installation 安装电器盖板






4 Lamp installation 安装灯管



5 Louver installation 安装格栅



Mesh plate installation 安装网板



1. The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
灯具应由有资格的电工安装，接线要符合IEE电气标准或国家标准。
2. The luminaire shall, under no circumstance, be covered with insulation matting or similar material.
灯具不适合被隔热或类似材料覆盖。