


Philips T5 Essential Batten TCH086

User Manual

使用说明书

Caution 注意事项:

- Please read this manual carefully before using the product.
使用前, 请先阅读本说明书。
- Please keep the manual for reference later.
请保留本说明书作为日后参考。
- The manufacturer will not be responsible for damage caused by improper usage or modifications of the product.
所有不当使用或自行更改产品结构而导致损坏, 生产商不负任何责任。
- The recommended maximum number of battens linked together is eight.
本灯具最多可八根支架串安装、使用。不允许在这些串联中间任何部位再串接其他非本支架电器产品。
- Max current of power cable: 2A.
电源线能承受的最大电流: 2A。



Operation Instruction 使用操作说明:

- Do not use the product in outdoor environments.
请勿在室外使用。
- The product is suitable for ceiling & wall mounting.
此灯具适用于墙壁和吸顶安装。
- Do not use in supply voltage exceeding 220-240V±10% for extended periods.
使用电压请勿超过220-240V±10%
- Do not touch the lamp when the power is switched on or few minutes after switching off.
亮灯使用时或关灯后数分钟, 请勿触摸光源发热部位。
- Do not place readily flammable material near the lamp.
请不要将高温易燃物品放在灯具附近, 以免引起火灾或触电。
- In case of operation failure, please switch off the power and contact your nearest Philips dealer.
如发现异常或操作有任何问题, 请务必先切断电源, 然后与飞利浦经销商联系。

Attention: Please switch off the power supply before changing the product or connection!

注意: 更换灯具或接线时, 请务必先关闭电源!

Conformance to: GB7000.201, GB7000.1, GB17743, GB17625.1

符合国标: GB7000.201, GB7000.1, GB17743, GB17625.1

顾客免费热线: 800-820-1201

Free hot line: 800-820-1201 (Only for PRC)

Specification 技术参数


Type 规格	Voltage/Frequency 电压/频率	Power Factor 功率因素	Color Temp 色温	Average Life Time(h) 平均寿命	Dimension(LxWxH) 尺寸(LxWxH)
8W	220-240V~/50/60Hz	0.6	6500K/4000K 3000K/2700K	10000	325.5 × 26 × 42mm
14W	220-240V~/50/60Hz	0.6		10000	585.5 × 26 × 42mm
21W	220-240V~/50/60Hz	0.6		10000	885.5 × 26 × 42mm
28W	220-240V~/50/60Hz	0.95		10000	1185.5 × 26 × 42mm

Electrical insulation classification/灯具绝缘等级: II

Batten installation 灯具安装

1 Individual mounting 单根安装

Installation on ceiling or wall through mounting clips.
使用安装附件安装在天花板或墙壁上。



Mounting distance(L) 安装距离 (L)	Units (mm) 单位 (mm)
8W	200-260
14W	300-500
21W	600-800
28W	800-1100

2 Wire connection I 导线连接 I

Use 2-pin plug* for power connection.
使用两相插头*连接电源线。

*2-pin plug is not provided.
两相插头不作为配件提供。

3 Wire connection II 导线连接 II

Using wire connection box* for power connection.
使用电线接线盒*连接电源线。

*Wire connection box is not provided.
电线接线盒不作为配件提供。

4 Linking method I 串接方式 I

Click fit male plug part into female socket. Affix next system, only after linking.
将灯具公插一端接入另一根灯具母插, 在串接动作完成后, 再串接下一根灯具。

Maximum amount of linking: 8pcs
最大串接数: 8PCS

5 Linking method II 串接方式 II

Use connector jack cable (Not provided in this pack) for linking, as required.
如需用的话, 利用串接线进行连接 (串接线需另行购买)。

Maximum amount of linking: 8pcs
最大串接数: 8PCS

Lamp replacement 光源更换

Please switch off and disconnect power before lamp replacement.
更换光源前, 请先断开电源。

PHILIPS T5 essential lamp is highly recommended to ensure optimal system performance.

推荐使用飞利浦T5标准光源, 以保证系统高效率运行。

Lamp replacement 光源更换

Take off the lamp cover.
取下光源端头保护盖。

Rotate to release lamp and replace with a new one.
旋转取下光源, 更换新光源。

Install the lamp cover.
安装光源端头保护盖。

用户资料

用户姓名: _____ 身份证号码: _____
地址: _____ 邮政编码: _____
联系电话: _____ 产品型号: _____
出售单位及地址: _____
购买日期: _____ 年 月 日 发票号码: _____
飞利浦照明

上海办事处
上海市沪宜公路1805号
电话021 59151088传真021 59151804邮编201801

成都办事处
成都市人民南路二段16号川信大厦28层
电话028 86199799传真028 86200703邮编610016

北京办事处
北京市朝阳区光华路9号世贸天阶大厦10层
电话010 85273888传真010 65016371邮编100020

广州办事处
广州市越秀区中山三路33号中华国际中心B塔18楼
电话020 83141682传真020 8377754/8377542邮编510055

武汉办事处
武汉市汉口建设大道568号新世界国贸大厦35层02-03室
电话027 85560332传真027 85793397邮编: 430022

沈阳办事处
沈阳市和平区南京北街206号城市广场第一座11层1103室
电话024 23341635传真024 23341632邮编110001

南京办事处
南京市汉中路2号金陵饭店世界贸易中心6楼
电话025 86556588传真025 84718215邮编210005

FOR CHINA ONLY

飞利浦灯具产品
专用保修证书
保修条例

本公司保证该产品在正常使用及保养下能够发挥其优越性能, 同时本公司将为持证用户提供一年之保修服务 (不含光源)。

- 1 自购买日期起一年内, 凡经本公司维修人员确认为正常使用情况下因制造工艺或材料而导致的故障及损坏, 您都将获得免费門市维修服务。
- 2 此免费保修服务包括附件、辅助装置、运输费及维修人员上门服务费。
- 3 维修时, 保修证及发票正本或其他有效证明同时使用方为有效。
- 4 以下情况将不能享受免费服务:
 - 1) 接不当电源, 使用不当之安装而造成的损坏。
 - 2) 非经本公司认可之维修和改装而造成的损坏。
 - 3) 错误或疏忽使用或不适当配件而造成的损坏。
 - 4) 因运输及其他以外而造成的损坏。
- 5 此证若经涂改即作废。
- 6 此证仅限在中国境内使用有效。

顾客热线: 8008201201 飞利浦灯具 (上海) 有限公司

飞利浦照明

FOR CHINA ONLY