

INSTALLATION INSTRUCTIONS

Philips Lighting North America Corporation
200 Franklin Square Drive,
Somerset, NJ 08873, USA

Philips Lighting Canada Ltd.
281 Hillmount Road,
Markham ON, Canada L6C 2S3



ELECTRICAL SHOCK HAZARD

READ, UNDERSTAND, and FOLLOW these instructions before installing the equipment.

WARNING

Disconnect the Electrical supply power at the service panel (fuse or circuit breaker box). Failure to do so could result in serious injury or death. Only qualified electricians should install this fixture and the installation **MUST** conform to the National Electrical Code Part I and all local codes and ordinances. Ensure that only proper tools, materials, and equipment are used to complete the installation.

SAFETY


- Proper grounding is required to ensure personal safety.
- Servicing this equipment should be performed by qualified service personnel.
- Save these instructions.

INSTALLATION

KNUCKLE MOUNT


The fixture has ½" NPS locking swivel knuckle that is suitable for mounting with a junction box or into a landscape post (sold separately). **NOTE: Use appropriate size junction box and/or landscape post depending on the size of fixture being mounted.**

- Seal arm thread using Teflon tape or silicone sealant.
- Pull the wires into the hole of the junction box or landscape post (not provided).
- Connect the wires properly in the junction box or landscape post. See Wiring Diagram
- Secure the fixture to junction box or landscape post by screwing the locking swivel knuckle into the cover.
- If applicable, plug all unused holes and seal threads with silicone.
- Loosen the screw on swivel portion of the knuckle, adjust the fixture to a suitable orientation, and then tighten the screw.



WIRING

- Make sure that the mains voltage is appropriate and conforms with the luminaire driver.
- Connect fixture **GROUND** (green) wire to power supply **GROUND** (green) wire.
- Connect fixture **WHITE** wire to power supply **(-) COMMON** wire.
- Connect fixture **BLACK** wire to power supply **(+)LINE** wire.



INSTRUCTIONS D'INSTALLATION

Philips Lighting North America
Corporation
200 Franklin Square Drive,
Somerset, NJ 08873, USA

Philips Lighting Canada Ltd.
281 Hillmount Road,
Markham ON, Canada L6C 2S3



RISQUE D'ÉLECTROCUTION

LIRE, COMPRENDRE, et SUIVRE ces instructions avant d'installer l'équipement.

AVERTISSEMENT

Débranchez l'alimentation électrique au panneau de service (de fusible ou de disjoncteur). Ne pas le faire pourrait entraîner des blessures graves ou la mort. Seul un électricien qualifié doit installer cet appareil et l'installation doit conformer au code électrique nationalité Partie I et tous les codes et règlements locaux. S'assurer que seuls les outils, les matériaux et l'équipement approprié est utilisé pour effectuer l'installation.

SÉCURITÉ

- Pour votre sécurité, il est nécessaire d'effectuer une mise à la terre appropriée.
- Entretien de cet équipement doit être effectuée par un personnel qualifié.
- Conservez ces instructions pour référence future.


INSTALLATION

MONTAGE AVEC JOINT D'ARTICULATION

Le luminaire est muni d'un joint d'articulation à verrouillage de 1/2 po NPS qui convient au montage sur une boîte de jonction ou sur un couvercle de boîte de jonction (vendu séparément). **REMARQUE**

Utilisez une boîte ou un couvercle de boîte de jonction approprié à la taille du luminaire installé.

- Étanchéifier le fillet de fixation à l'aide d'un ruban en téflon ou d'un joint de silicone.
- Faites passer les fils dans le trou de la boîte de jonction ou du couvercle (non inclus).
- Branchez correctement les fils dans la boîte de jonction ou dans le couvercle. Voir Directives de câblage.
- Installez le luminaire sur la boîte de jonction ou sur le couvercle en y vissant le joint d'articulation à verrouillage.
- Desserrez la vis de la partie pivotante du joint d'articulation, orientez le luminaire dans la direction appropriée, puis resserrez la vis.



DIRECTIVES DE CÂBLAGE

- Assurez-vous que la tension secteur est appropriée et conforme avec le Driver du luminaire.
- Branchez le fil de MISE A LA TERRE (vert) du luminaire au fil de MISE A LA TERRE (vert) de l'alimentation.
- Branchez le fil BLANC du luminaire au fil NEUTRE de l'alimentation.
- Branchez le fil NOIR du luminaire au fil de LIGNE de l'alimentation.

