


Tunnel Lighting



M/SRX509

Mounting instruction 安装说明


4441 000 65322



Type Number 型号	Lamp 光源	Voltage/Frequency 电压/频率	Glass 玻璃	Weight 重量(kg)	Reflector 反射器
SRX509	SON-T 100W	220V/50Hz	FG (平面)	13	S
	SON-T 150W	220V/50Hz		13.6	S/A
		240V/50Hz			A
	SON-T 250W	220V/50Hz		14.5	S/A
	SON-T 400W	220V/50Hz		16.1	S/A
		240V/50Hz			A



Install the Luminaire 灯具安装




Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huiyi Road, Jiading, Shanghai, China
Postalcode: 201801
飞利浦灯具（上海）有限公司
地址：中国上海市嘉定区马陆镇沪宜公路
邮编：201801

PHILIPS


1

Open the glass cover and replace the lamp
打开防护玻璃与更换光源



2

Connect entry cable
进线连接



3

Close the glass cover
关闭防护玻璃

