

# Installing accessory in enclosed Sof-tech

## Read and understand these instructions before installing luminaire.



This luminaire is intended for installation in accordance with the National Electrical Code and Local Regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

## Retain these instructions for maintenance reference.

1. Make certain that power is off and FIXTURE is cool.
2. Place LENS, LOUVER, or FILTER in the LENS HOLDER as shown (Fig. 1).
3. Press assembled LENS HOLDER over opening of FIXTURE and press firmly until engaged. (Fig. 2).

FIXTURE NO.	LENS HOLDER	LOUVER (HEX CELL)	COLOR FILTER	SPREAD LENS	BEAM SMOOTHER	BEAM ELONGATOR
8416 **	8471	AL2HC	AF2 SERIES*	AF2SY	AF2LF	AF2AS
8420	8472	AL25HC			AF25LF	AF25AS
8430	8473	AL3HC			AF3LF	AF3AS

NOTE: \* DO NOT USE BLUE FILTER NO. AF2BL  
 \*\* WHEN USING ACCESSORIES, USE PAR 16 60W MAX BY OSRAM/SYLVANIA



\* SEE CHART