




Installation instructions


Instructions de montage Instrucciones de montaje Kokoonpano- ja kiinnitysohjeet Szerelési utasítások
Montageanleitung Instruções de montagem Montaj yönergeleri Návod k montáži
Montage instructie Monteringsinstruktioner Ο δ ή ε γ ν ι σ υ ν α λ μ η ρ α λ η ρ ? ИНСТРУКЦИЯ ПО МОНТАЖУ
Istruzioni di montaggio Monteringsvejledning Instrukcja montazu Návod k montáži



		A	B		
TCS165	2xTL5-28W	1196	296	920 x 244 (L x W)	3.4
	3xTL5-14W	596	596	320 x 544 (L x W)	3.0
	4xTL5-14W				3.1
A luminária está com pré instalação feita para utilização de reator simples. Se for utilizado reator dimerizável é necessário rever a instalação.					




PHILIPS




The luminaire shall, under no circumstances, be covered with insulating matting or similar material. !



1





2a




2b




3a




3b




1



2



3



3c

