

by (Signify

Signify North America Corporation 200 Franklin Square Drive Somerset, NJ 08873 Telephone 855-486-2216

Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008

INSTALLATION INSTRUCTIONS: HFP910



Read These Instructions Carefully Before Installing This Fixture!



ATTENTION:

All wiring must be done by a qualified electrician.



WARNING:

Make sure that power is disconnected before performing installation and maintenance on this fixture.



WARNING:

Install, operate and maintain to meet all applicable codes.



WARNING:

This fixture is intended to be wired in accordance with the National Electrical Code and local code specifications. Failure to adhere to these codes may result in serious personal injury.

32001618, revision D page 1 of 2



Installation Steps:

- 1. Make sure that power is disconnected.
- 2. Make wire connections from pole to outwires at bottom of arm.
- 3. Slip arm assembly onto pole tenon (3"O.D. x 9" tall). Be careful not to pinch wires.
- 4. Rotate arm assembly to desired orientation.
- 5. Tighten (9) factory installed 3/8" hex head bolts to pole tenon.
- 6. Attach luminaire adaptor (Hadco TFHAM recommended) and/or luminaire to end of arm assembly per manufacturer's instructions.

7. Reconnect power supply.

32001618, revision D page 2 of 2