LIGHTOLIER

by (s) ignify


Instruction Sheet Number | S:1104|CX

Page 1 of 2

Installation Procedure for high wattage IC FRAME IN KITS 1004ICX, 1004ICXN, 1104ICX, 1104ICXN READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING THE LUMINAIRE.

This fixture is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding. Retain these instructions for maintenance reference and warranty information.


NEW CONSTRUCTION - NOTE: I.C. Frame-In Kit may be used in direct contact with insulation.




WARNING: USE ONLY WITH LIGHTOLIER REFLECTOR TRIMS MARKED WITH LC. LAMPING INFORMATION. USE OF OTHER MANUFACTURERS' TRIMS VOIDS THE UNDERWRITERS LABORATORIES LISTING AND COULD CONSTITUTE A FIRE HAZARD

1. Frame-In (Fig. A):

Locate fixture along joist and line up bottom edge of HINGED MOUNTING BAR with the bottom of joist and fasten in place.







FOR JOIST SPACING LESS THAN 16" ON CENTER (TO 12" ON CENTER):


MOUNTING BAR CHANNELS can be shortened and used as nailing legs in tight spaces. Simply remove INNER BAR from holed CHANNEL, bend CHANNEL to appropriate point and use extra screw to secure to the joist. (Fig G.)

For Sloped Ceilings:

For 1131 and 1133 series sloped ceiling trims, Mounting Frame must be mounted with J-Box on the "downhill" side. Mounting Frame should be parallel to the joist.


© 2018 Signify Holding. All rights reserved. This document may be subject to change. No representation

or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance there on is disclaimed. The information presented in this document is not intended as any commercial offer. All trademarks are owned by Signify Holding or their respective owners.



For suspended ceilings:

- Rotate HINGED BAR ENDS to position shown below and fully extend bars.
- Crimp bottom of edge of CHANNEL to prevent rotation of HINGED BAR ENDS.
- Bend NON-HINGED end of mounting bar at featured hole location and extend out.
- Position notched area of MOUNTING BARS onto T-BAR and lock by bending TAB underneath T-BAR BEAD as shown.
- For suspended ceiling, make certain that bottom of MOUNTING FRAME is no higher than 1" above ceiling line



Signify North America Corporation 200 Franklin Square Drive Somerset, NJ 08873, USA Phone: 855-486-2216

Signify Canada Ltd./ Signify Canada Ltée 281 Hillmount Road Markham ON, Canada L6C 2S3 Phone: 800-668-9008

www.lightolier.com

LIGHTOLIER

by (s)ignify

Instruction Sheet Number IS:1104ICX

Page 2 of 2

Installation Procedure for high wattage IC FRAME IN KITS 1004ICX, 1004ICXN, 1104ICX, 1104ICXN

2. Wire-In: (Fig. B)

Open hinged J-BOX COVER fully to its locked position (lift slightly to unlock).

Option 1: Remove one of the provided KNOCK OUTS. Insert supplied (or Equivalent) snap in NON-METALLIC CABLE CLAMP into KNOCK OUT. Push cables through single CLAMP.

Note: Snap in supplied CLAMP: Fits NM CABLES #14/2, #14/3, #12/2, #10/2, #10/3

Option 2: Open hinged KNOCK OUT to allow NON-METALLIC CABLE to enter JUNCTION BOX. Push CABLE through CLAMP.

Note: Wiring and connections must not be placed in JUNCTION BOX in a manner which will interfere with the CLAMPS action to provide strain relief.

Wire to SUPPLY LEADS. WHITE FIXTURE LEAD to NEUTRAL SUPPLY LEAD. BLACK FIXTURE LEAD to HOT (120V) SUPPLY LEAD. BARE FIXTURE WIRE to SUPPLY GROUND. Use wirenuts (local hardware item). Place all electrical connections in the J-BOX and close the J-BOX COVER.

3. Swing-Up (Fig. C):

Extend MOUNTING BAR to reach opposite joist and fasten in place. Adjust FRAME-IN KIT to desired position along MOUNTING BAR and lock in place using locking screw.

4. Close-In (Fig. D):

Install plasterboard or other dry type ceiling. Hole in board can be cut either on the floor or after the board is secured to the ceiling using MOUNTING FRAME opening as cutting guide. Make sure ROTO-CLIPS are rotated out of hole area to be cut, also making sure that socket and wiring are positioned away from hole area. Roto Clips can only be rotated counter-clockwise. This detail allows easy removal of reflector trim by rotating TRIM counterclockwise and permits installing Reflector Trim tightly against ceiling surface by rotating trim clockwise after pushing trim into ceiling.

NOTE: When using 1116, 1117, 1117WH Trims, ceiling thickness should be 3/4" maximum.

5. AirSeal[®] Installation (Optional):

Install a bead of silicone caulking compound between the ceiling opening and edge of HOUSING. HOUSINGS are tested in accordance with ASTM E 283 (max 2 cfm @ 75 pa) and comply with WSEC & MEC when installed as instructed.

6. SNAP-ON: (Fig. E)

Important - Insert SOCKET CUP in neck of REFLECTOR making sure SPRING TABS fully engage into SLOTS in REFLECTOR.


7. PUSH-UP (Fig. F)


Push REFLECTOR TRIM straight up until it is tight against ceiling.

SEE SEPERATE REFLECTOR TRIM INSTRUCTION SHEETS



Option 2:





© 2018 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance there on is disclaimed. The information presented in this document is not intended as any commercial offer. All trademarks are owned by Signify Holding or their respective owners.

Signify North America Corporation 200 Franklin Square Drive Somerset, NJ 08873, USA Phone: 855-486-2216 Signify Canada Ltd./ Signify Canada Ltée 281 Hillmount Road Markham ON, Canada L6C 2S3 Phone: 800-668-9008