


LED Underwater / LED 水下灯

BCPI70 LED400

Mounting instruction 安装说明




Type Number 产品型号	LEDs 颗粒数	Power 功率	Voltage 电压	Frequency 频率	
BCPI70 LED400	9	18.0W	DC12V		2.5KG




- 1 Confirm all components received.  
确认收到了所有部件

Length: 3M  
线长: 3M



棕色线-DC12V+	Brown wire-DC12V+
蓝色线-DC12V-	Blue wire-DC12V-
黑色线-Data+	Black wire-Data+
灰色线-Data-	Gray wire-Data-

- 2 Record location and serial number of each fixture for addressing.  
记下各灯具的位置和序列号, 以便查询




- 3 Make sure power is OFF  
确保电源关闭




The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.  
灯具应由有资格的电工安装, 接线要符合IEE电气标准或国家标准。

- 4 Connect fixture within maximum length  
在最长接线长度内连接灯具




说明: 本产品仅适用标准512 DMX控制协议



## LED Underwater / LED 水下灯


BCPI70 LED400

Mounting instruction 安装说明




### 5 Drain Before Mounting 安装之前请先将水排干

### 6 Mount Fixture 安装灯具



### 7 Connect fixture cable 连接灯具电线



## LED Underwater / LED 水下灯

BCPI70 LED400


Mounting Instruction 安装说明

8 Turn the power ON

打开电源


9 Rotate and aim fixture

旋转并对准灯具




10 Lock fixtures in place

固定灯具



Do not look into beam

切勿直视光束




Do not loosen sealing bolts

请勿拧松密封螺栓



11 Fill

注水



Note: For use only when immersed in water!

注意：只能浸入水中使用！



Can be used in human occupied pool

适合于有人活动的游泳池



Philips Lighting Luminaires (Shanghai) Co., Ltd.  
Address: No. 2688, Huyi Road, Jiading, Shanghai, China  
Postalcode: 201801

飞利浦灯具（上海）有限公司

地址：中国上海市嘉定区马陆镇沪宜公路2688号

邮编：201801

# PHILIPS