

# Green Perform LED Highbay

BY687P

Mounting instruction

4441 700 95361



Description	CCT	Optics	Frequency	Voltage	kg	Wattage	Dimension		
							Type	Dimension (mm)	
BY687P LED200 L3000/CW PSR S-WB PC	CW	WB	50/60Hz	220-240V~	9.5	200W	D	W	H
BY687P LED200 L3000/CW PSR S-NB PC		NB							
BY687P LED200 L3000/CW PSR S-HRO PC		HRO							
BY687P LED200 L3000/NW PSR S-WB PC	NW	WB							
BY687P LED200 L3000/NW PSR S-NB PC		NB							
BY687P LED200 L3000/NW PSR S-HRO PC		HRO							
BY687P LED240 L3000/CW PSR S-WB PC	CW	WB			9.5	240W	D	W	H
BY687P LED240 L3000/CW PSR S-NB PC		NB							
BY687P LED240 L3000/CW PSR S-HRO PC		HRO							
BY687P LED240 L3000/NW PSR S-WB PC	NW	WB							
BY687P LED240 L3000/NW PSR S-NB PC		NB							
BY687P LED240 L3000/NW PSR S-HRO PC		HRO							
BY617Z MB	Suspension kits to be ordered separately								
MOUNTING HOOK									

## 1 Installation

### Hook mounting

Luminaire doesn't include this chain. Hook to be ordered separately.

### Pipe mounting

Luminaire doesn't include this pipe. Pipe dim. is shown as G1/2" with a height of 20-25mm.

### Bracket mounting

Bracket to be ordered separately. Mounting hole dimension is shown as 130±0.2mm.

## 2 Cable Connection

### 1

Dimming Cable      Entry Cable

### 2 Connect Dimming Cable

Cable Requirement:  
 60227IEC53 2 x 1-1.5mm<sup>2</sup>  
 60245IEC57 2 x 1-1.5mm<sup>2</sup>

### 3 Connect Entry Cable

Cable Requirement:  
 60227IEC53 3 x 1-1.5mm<sup>2</sup>  
 60245IEC57 3 x 1-1.5mm<sup>2</sup>

1. The luminaire must be installed by a qualified electrician and wired in accordance with the local wiring regulations.
2. The luminaire shall, under no circumstance, be covered with thermal insulation matting or similar material.
3. When cleaning the product, please use dry soft cotton cloth only.
4. For indoor use only at room temperature.
5. This is a general purpose luminaire, it should not be used in directly exposed environment containing hazardous substances for PC, consult your local Philips office for use in any special applications.
6. LED module and PC Cover cannot be replaced. If damaged, the luminaire shall be destroyed.
7. The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.