

This luminaire is intended for installation in accordance with Local Code and regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding. Allow fixture to cool before handling. Retain these instructions for maintenance reference.

INSTRUCTIONS FOR INSTALLING AND OPERATING 22MW4 & 22MW4R LOW VOLTAGE ALCYON™ LUMINAIRES. FOR USE WITH LIGHTOLIER LYTESPAN® TRACK.

INSTRUCTIONS FOR ATTACHING A LOW VOLTAGE ALCYON™ LUMINAIRE TO SINGLE CIRCUIT LYTESPAN® TRACK AND ACCESSORIES:

CAUTION: HOT SURFACE. Keep away from curtains and any other combustibles.

1. Turn off power to TRACK.
2. Insert luminaire into TRACK as shown in FIG. 1. The STEM must be on the same side as the BEAD.
3. Rotate TRANSFORMER HOUSING 90° clockwise (see FIG. 1) until it snaps in place (see FIG. 2).
4. TO REMOVE: Lightly pull down TRANSFORMER HOUSING and rotate counterclockwise.

INSTRUCTIONS FOR CONVERTING A LOW VOLTAGE ALCYON LUMINAIRE TO OPERATE ON 2 CIRCUIT ADVENT™ LYTESPAN® TRACK:

TO POWER ON (L1) LOWER CIRCUIT (See FIG. 4):
Follow instructions above for installing to a single circuit Lytespan® Track.

TO POWER ON (L2) UPPER CIRCUIT (See FIG. 4):

1. Raise BRASS CONTACT to high position by pulling CONTACT as high as stop permits (See FIG. 3).
2. Follow instructions above for installing into track.

CAUTION: RISK OF BURN. Allow time for luminaire to cool before touching track head for relamping or positioning.

INSTRUCTIONS FOR LAMPING 22MW4CE LOW VOLTAGE ALCYON™ LUMINAIRE:

1. Turn off power to TRACK.
2. Remove GLASS HOLDER FRAME by depressing and pulling on SPRING as shown in FIG. 5.
3. Install LAMP (50W MAX., 12V T4 2-pin-GY6.35 base. Clear with horizontal filament) into the socket by inserting the LAMP PINS into the SOCKET HOLES as far as they will go. PINS will be exposed approximately 1/8" outside of the socket when fully inserted. No polarity of pins required. (See FIG. 6)
4. Reassemble GLASS HOLDER FRAME by inserting TAB into SLOT and rotating until SPRING snaps tight and is secure in HOUSING (See FIG. 5 & 6).

NOTE: According to manufacturer's instructions, the lamp should not be touched with bare hands. Hold with a clean cloth or paper when installing. If touched, wipe with a clean cloth before lighting.

INSTRUCTIONS FOR POSITIONING LOW VOLTAGE ALCYON™ LUMINAIRES:

1. Turn off power to TRACK and allow time for luminaire to cool.
 2. Rotate HOUSING horizontally and vertically as shown in FIG. 7.
- NOTE:** Luminaires rotate infinite horizontally and 90° vertically. Forcing past vertical rotation stop could permanently damage luminaire.

