

Cabana 2 BY150P

Mounting instructions

Instructions de montage
Montageanleitung
Montage instructie
Istruzioni di montaggio

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergesi
Návod k montáži
Instrukcja montażu

Szerelési utasítások

IEC
EN60598









IP65










IK08



ta35°C

		250W	400W
BY150P 1xSON250/400W IC	SON 250W/400W E40	9,8	11,6
BY150P 1xSON250/400W AUX IC	SON 250W/400W E40 EcoClassic30 105W E27 230V T32	10,4	12,1
BY150P 1xSON250W EL1 IC	SON 250W E40 MASTER PL-C 18W/840/4P	10,8	x
BY150P 1xHPI-P250/400W-BU IC	HPI-P 250W/400W/745 BU E40	8,8	10,8
BY150P 1xHPI-P250/400W-BU AUX IC	HPI-P 250W/400W/745 BU E40 EcoClassic30 105W E27 230V T32	11,1	11,8
BY150P 1xHPI-P250W-BU EL1 IC	HPI-P 250W/745 BU E40 MASTER PL-C 18W/840/4P	11,5	x





Accessories:

- 1. Reflector: BY150G R
- 2. Glass: BY150Z GC
- 3. Bracket: BY150Z MB
- 4. Hooks: BY150Z CH