


Read and understand these instructions before installing luminaire

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference

Note: This instruction sheet covers several trim types and styles. Although the illustration may not depict the product exactly, the installation remains the same.



Frame-In Kit Installation:

1. See frame-in kit instruction sheet for installation procedure.

Installation Instructions For Decorative Attachment:

1. Insert TRIM RING MOUNTING SCREWS (4X) into TRIM MOUNTING RING and up into MOUNTING FRAME HOLES (FIG. 1). MOUNTING FRAME HOLES are located on centerline of SPRING POCKETS and are marked with a letter "A" (Fig 2). To attach OUTER GLASS ASSEMBLY (O.G.A.), after inserting TRIM RING MOUNTING SCREWS into TRIM MOUNTING RING slide the TRIM RING MOUNTING SCREWS through holes in top of O.G.A. MOUNTING RING then up into MOUNTING FRAME HOLES as instructed above.

2. Secure TRIM RING MOUNTING SCREWS with KNURLED NUTS. Reach through MOUNTING FRAME aperture opening and place KNURLED NUTS onto TRIM RING MOUNTING SCREWS. Tighten down KNURLED NUTS until TRIM MOUNTING RING is tight to FINISHED CEILING.

3. Discarding the white plastic trim ring. Insert the trim section into the frame-in kit. See trim section instruction sheet for installation procedure.

4. Lamp the fixture. Install recommended lamp.

5. Align TRIM MOUNTING TABS on top of DECORATIVE ELEMENT with SLOTS in TRIM MOUNTING RING. Push DECORATIVE ELEMENT up until DECORATIVE ELEMENT bottoms out on TRIM MOUNTING RING. Rotate DECORATIVE ELEMENT clockwise until it clicks into place.

Read and understand these instructions before installing luminaire

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference

| DECORATIVE TRIM | FRAME-IN KIT - FLUORESCENT LAMP | REFLECTOR | INNER GLASS UNIT | OUTER GLASS UNIT |
|-----------------|---|-----------|------------------|------------------|
| D4A01, D4A02 | 4118VU,4118VCU3,4118VJUM7, D4132VU, D4132VULC | 8011CL | N/A | N/A |
| D4A03 | | | D4A03 | N/A |
| D4A04 | | | D4A04 | N/A |
| D4A13 | | | D4A03 | 72314 |
| D4A14 | | | D4A04 | 72319 |
| D6A01, D6A02 | S6132BU,S6132BUES, S6132BCU3,S6132BJUM7 S6142VUX4 | 8021CL | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72315 |
| D6A14 | | | D6A04 | 72320 |
| D6A01, D6A02 | S6132 | 8091,8031 | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72315 |
| D6A14 | | | D6A04 | 72320 |
| D6A01, D6A02 | 6213 | 8052 | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72315 |
| D6A14 | | | D6A04 | 72320 |
| D6A01, D6A02 | 6218 | 8051 | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72315 |
| D6A14 | | | D6A04 | 72320 |
| D7A01, D7A02 | S7142BU,S7142BCU3,S7142BJUM7 | 8022CL | N/A | N/A |
| D7A03 | | | D7A03 | N/A |
| D7A04 | | | D7A04 | N/A |
| D7A13 | | | D7A03 | 72316 |
| D7A14 | | | D7A04 | 72321 |

Read and understand these instructions before installing luminaire

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference

| DECORATIVE TRIM | FRAME-IN KIT - FLUORESCENT LAMP | REFLECTOR | INNER GLASS UNIT | OUTER GLASS UNIT |
|-----------------|---------------------------------|-----------|------------------|------------------|
| D7A01, D7A02 | 7126 | 8056 | N/A | N/A |
| D7A03 | | | D7A03 | N/A |
| D7A04 | | | D7A04 | N/A |
| D7A13 | | | D7A03 | 72316 |
| D7A14 | | | D7A04 | 72321 |
| D7A01, D7A02 | S7142 | 8097,8037 | N/A | N/A |
| D7A03 | | | D7A03 | N/A |
| D7A04 | | | D7A04 | N/A |
| D7A13 | | | D7A03 | 72316 |
| D7A14 | | | D7A04 | 72321 |
| D7A01, D7A02 | 7218 | 8096,8056 | N/A | N/A |
| D7A03 | | | D7A03 | N/A |
| D7A04 | | | D7A04 | N/A |
| D7A13 | | | D7A03 | 72316 |
| D7A14 | | | D7A04 | 72321 |
| D7A01, D7A02 | S7226 | 8096,8056 | N/A | N/A |
| D7A03 | | | D7A03 | N/A |
| D7A04 | | | D7A04 | N/A |
| D7A13 | | | D7A03 | 72316 |
| D7A14 | | | D7A04 | 72321 |

| DECORATIVE TRIM | FRAME-IN KIT - LED'S | REFLECTOR | INNER GLASS UNIT | OUTER GLASS UNIT |
|-----------------|----------------------|-----------|------------------|------------------|
| D4A01, D4A02 | C410LED C4L05N | C4L05DL | N/A | N/A |
| D4A03 | | | D4A03 | N/A |
| D4A04 | | | D4A04 | N/A |
| D4A13 | | | D4A03 | 72314 |
| D4A14 | | | D4A04 | 72319 |
| D4A01, D4A02 | C420LED C4L10N | C4L10DL | N/A | N/A |
| D4A03 | | | D4A03 | N/A |
| D4A04 | | | D4A04 | N/A |
| D4A13 | | | D4A03 | 72314 |
| D4A14 | | | D4A04 | 72319 |

Read and understand these instructions before installing luminaire

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference

| DECORATIVE TRIM | FRAME-IN KIT - LED'S | REFLECTOR | INNER GLASS UNIT | OUTER GLASS UNIT |
|-----------------|----------------------|-----------|------------------|------------------|
| D6A01, D6A02 | C6L15,C6L20 | C6L1520DL | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72314 |
| D6A14 | | | D6A04 | 72319 |
| D7A01, D7A02 | | | C7L15,C7L20 | C7L1520DL |
| D7A03 | D7A03 | N/A | | |
| D7A04 | D7A04 | N/A | | |
| D7A13 | D7A03 | 72314 | | |
| D7A14 | D7A04 | 72319 | | |

Read and understand these instructions before installing luminaire

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference

| DECORATIVE TRIM | FRAME-IN KIT - LED'S | REFLECTOR | INNER GLASS UNIT | OUTER GLASS UNIT |
|-----------------|----------------------|-----------|------------------|------------------|
| D6A01, D6A02 | C6L15,C6L20 | C6L1520DL | N/A | N/A |
| D6A03 | | | D6A03 | N/A |
| D6A04 | | | D6A04 | N/A |
| D6A13 | | | D6A03 | 72314 |
| D6A14 | | | D6A04 | 72319 |
| D7A01, D7A02 | | | C7L15,C7L20 | C7L1520DL |
| D7A03 | D7A03 | N/A | | |
| D7A04 | D7A04 | N/A | | |
| D7A13 | D7A03 | 72314 | | |
| D7A14 | D7A04 | 72319 | | |