



# Fusion III

120VAC OR 277VAC  
Two Circuit Input

## IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed, including the following:

### READ AND FOLLOW ALL SAFETY INSTRUCTIONS

All servicing should be performed by qualified personnel only.

Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.

The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.

Do not use this equipment for other than intended use.

Do not let supply cords touch hot surfaces.

Do not mount near gas or electric heaters.

Caution: Halogen cycle lamp(s) are used in this equipment. To avoid shattering: Do not operate lamp in excess of rated voltage, protect lamp against abrasion and scratches and against liquids when lamp is operating, dispose of lamp with care.

Halogen cycle lamps operate at high temperatures.



## INSTALLATION AND OPERATING INSTRUCTIONS

Do not store or place flammable materials near lamp. Use caution when servicing batteries. Battery acid can cause burns to skin and eyes. If acid is spilled on skin or eyes, flush acid with fresh water and contact a physician immediately.


CAUTION: To avoid electrical overload, total connected lamp load (factory and field installed) should not exceed output rating.

### SAVE THESE INSTRUCTIONS

**WARNING** – Shut off AC power to branch circuits to which units will be connected. All wiring should be per N.E.C. Articles 501-4(b) and local codes.

To maintain warranty, equipment with batteries must be installed or placed on charge within prescribed period after shipment.

### GENERAL INSTRUCTIONS



#### STEP 1


Remove cover assembly by pulling straight off of housing assembly (there are two spring clips that hold them together). Set cover assembly aside.



Philips Lighting North America Corporation  
200 Franklin Square Drive  
Somerset, NJ 08873, USA  
Phone: 855-486-2216  
[www.philips.com/luminaires](http://www.philips.com/luminaires)

Philips Lighting Canada Ltd.  
281 Hillmount Road,  
Markham ON, Canada L6C 2S3  
Phone: 800-668-9008  
[www.philips.com/luminaires](http://www.philips.com/luminaires)

9140053155  
February 2016



**STEP 2**

For surface mounting, a knockout pattern is supplied for 3-1/2” octagonal or single gang junction boxes. Remove desired mounting knockouts and the rectangular knockout found in the lower center area of the housing. The rectangular knockout will allow for AC supply entry. (The LED’s may be seen to flash while striking the knockouts for removal. The battery may be temporarily disconnected to eliminate this if desired).


For recessed mounting, the packaging insert also functions as a template for cutting the correct size and shape opening in the mounting surface. A bar hanger kit is supplied. The bar hangers may be mounted to the housing assembly in either orientation shown depending upon desired mounting. A round conduit entry knockout is provided in the upper center or side of the housing.



Philips Lighting North America Corporation  
 200 Franklin Square Drive  
 Somerset, NJ 08873, USA  
 Phone: 855-486-2216  
[www.philips.com/luminaires](http://www.philips.com/luminaires)

Philips Lighting Canada Ltd.  
 281 Hillmount Road,  
 Markham ON, Canada L6C 2S3  
 Phone: 800-668-9008  
[www.philips.com/luminaires](http://www.philips.com/luminaires)


9140053155  
 February 2016



TWO-CIRCUIT AC HOOKUP	
<u>120 VAC OPERATION</u>	<u>277 VAC OPERATION</u>
White Wire - 1st Common	White Wire - 1st Common
Black Wire - 1st 120V Line	Blue Wire - 1st 277V Line
Orange Wire - 2nd 120V Line	Orange Wire - 2nd 277V Line
Yellow Wire - 2nd Common	Yellow Wire - 2nd Common
Green Wire - Ground	Green Wire - Ground

### STEP 3

Make AC supply connections. The input may be connected to either switched or unswitched AC service. Cap off unused 120VAC or 277VAC wire to prevent shorting.



### STEP 4

Reinstall cover assembly.



Philips Lighting North America Corporation  
 200 Franklin Square Drive  
 Somerset, NJ 08873, USA  
 Phone: 855-486-2216  
[www.philips.com/luminaires](http://www.philips.com/luminaires)

Philips Lighting Canada Ltd.  
 281 Hillmount Road,  
 Markham ON, Canada L6C 2S3  
 Phone: 800-668-9008  
[www.philips.com/luminaires](http://www.philips.com/luminaires)

9140053155  
 February 2016