


## INSTALLATION INSTRUCTIONS


This fixture must be installed by a qualified electrician

When fixture is being mounted to a 4" round pole or tennon adaptors use optional adaptor Part # FPMRPA.


- 1** Use supplied drill template to drill holes in pole.





Remove backing from adhesive on nut bar and insert into top of pole. Carefully align holes in bar to predrilled holes in pole.




Insert one 3/8-16 x 1 1/4" bolt into the top hole, leave 1/2" of the thread exposed.




 # 3/8-16 x 1 1/4" Bolt



 Washer




 # 3/8-16 x 7/8" Bolt

(A) Using keyhole feature in end of arm hang fixture on bolt.

(B) Insert washer.

(C) Insert # 3/8-16 x 7/8" bolt into lower hole and tighten. Torque bolts to 19ft lbs (180-200in lbs).

NOTE: When mounting to a 4" round pole or tennon adaptor with a FPMRPA, replace the # 3/8-16 x 7/8" bolt in step (C) with the supplied # 3/8-16 x 1 1/4" bolt.



Feed supply wires into arm wiring chamber.

Make connections to factory ballast supply leads according to local and national electrical codes.


Hinge cover into place and secure with screw to enclose wiring compartment.

Caution: Disconnect Power Before Servicing

## Servicing the Silhouette

### Driver Access

Removing the LED assembly and accessing the driver.



1. Loosen screws (4) and slowly remove cover.

NOTE: LED Light assembly is not field servicable. Contact factory for servicing. (800-334-2212)

Read instructions carefully before attempting to install fixture.  
Retain instructions for future reference.

#### GENERAL SAFETY INFORMATION

1. WARNING: Do not handle an energized fixture or energize any fixture with wet hands or when standing on a wet or damp surface, or in water.
2. External parts of fixture develop high operating temperatures. To avoid possible pain or injury, do not touch external parts of fixture when it is in operation.
3. Turn off power and allow fixture to cool before touching for any reason.
4. This fixture must be properly fused and wired in accordance with all electrical and safety codes and ordinances, as well as the most recent National Electric Code.
5. This fixture must be adequately grounded for your protection against shock hazards and to assure proper operation.
6. All wiring should be performed by a qualified licensed electrician.
7. Make certain that the power source conforms to the requirements of this fixture.
8. Disconnect power before installing or servicing. If the power disconnect switch is out of sight, lock it in the open position and tag it to prevent unexpected application of power.
9. This fixture is intended to be used for general lighting in a normal open-air ambient.
10. Do not install in dead air, sheltered, buried or boxed-in locations. This fixture should not be installed in areas that will entrap heat. It is not intended to be used in potentially dangerous locations such as flammable or explosive atmospheres.
11. Not for use in car washes.
12. Failure to follow above safety instructions could result in fatal shock or fire hazards.
13. This fixture is intended for ceiling mounting with approved fittings and accessories.

### Troubleshooting Guide

Symptoms	Possible Cause(s)	Corrective Action
Lamp does not light	1. No power to unit. 2. Loose wiring	1. Check circuit protection device (circuit breaker, fuse or switch). 2. Recheck wiring connections (with power off)

#### INSTALLATION

WARNING: Make sure that all power is turned off while installing unit. Do not turn power on until fixture is completely installed. Turn power off at circuit breaker box. Refer to appropriate Section.

#### Operation

Switch unit "on" using circuit breaker controlling unit.

#### Maintenance

Periodically check and remove any accumulated dirt or debris from the lens and around fixture.

#### Caution:

Installation of fixture in ambients above 40 degrees C will result in shortened life.

LED Radiation - Do not stare into beam.

Turn power off before installing or replacing.



© 2016 Philips Lighting Holding B.V. All rights reserved.  
www.philips.com/luminaires

443561049510/UN-59-02905-000 Rev. A  
Page 1 of 2

Philips Lighting North America  
Corporation  
200 Franklin Square Drive,  
Somerset, NJ 08873, USA

Philips Lighting Canada Ltd.  
281 Hillmount Road,  
Markham ON, Canada L6C 2S3