

INSTALLATION INSTRUCTIONS FOR VETRO SERIES**Read and understand these instructions before installing luminaire.**

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.


Retain these instructions for maintenance reference.

Note: This instruction sheet covers several luminaire types and styles. Although the illustration may not depict the product exactly, the installation remains the same.


Outer Glass Installation:

- 1) Unscrew LUMINAIRE UPPER BODY from LUMINAIRE LOWER BODY (fig. 1).
- 2) Insert GLASS SUPPORT RING onto the LUMINAIRE UPPER BODY with the hole from the GLASS SUPPORT RING towards the TOP COVER (fig. 2). Making certain wires and connections are not pinched, fully tighten the LUMINAIRE LOWER BODY to the LUMINAIRE UPPER BODY.
- 3) Slide the OUTER GLASS up around the LUMINAIRE BODY until holes in the OUTER GLASS line up with holes in GLASS SUPPORT RING. Insert one GLASS SUPPORT PIN through hole in OUTER GLASS and screw into GLASS SUPPORT RING, repeat for remaining GLASS SUPPORT PINS. Make certain GLASS SUPPORT PINS are screwed in tightly.

CAUTION: MAXIMUM WATTAGE AS MARKED ON LUMINAIRE MUST NOT BE EXCEEDED



DETAIL "A"
(FIG. 2)



(FIG. 1)