


**INSTALLATION INSTRUCTIONS FOR TRACK MOUNTED PENDANTS****Read and understand these instructions before installing luminaire.**

This luminaire is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.




**NOTE:** Not for use with ProSpec® track.

**Luminaire Installation:**


1. See Luminaire installation instructions supplied with luminaire.

**Installation Into Track :**

1. Turn off power to TRACK.
2. Insert SUSPENSION STEM into track. STEM LEVER must be on the same side as the track bead (fig. 1).
3. Rotate suspension stem 90° clockwise using STEM LEVER. STEM LEVER should be parallel to TRACK.
4. To remove: rotate SUSPENSION STEM 90° counterclockwise using STEM LEVER.
5. Once the SUSPENSION STEM is installed on TRACK add CABLE CLIPS (3X) (fig. 2). First slide AIRCRAFT CABLE into CABLE CLIP then POWER CORD.
6. When the CABLE CLIPS are in the desired position lightly crimp the CABLE CLIP to POWER CORD with a SMOOTH JAW PLIER so not to mar the finish of the CABLE CLIP.



(FIG. 1)



(FIG. 2)