

Philips Mini Iridium LED BGS 45 I

Mounting instructions

Instructions de montage

Montageanleitung

Montage instructie

Istruzioni di montaggio

Instrucciones de montaje

Instruções de montagem

Monteringsinstruktioner

Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet

Montaj yönergəsi

Οδηγίες συναρμολόγησης

Instrukcja montażu

Szerelési utasítások

Návod k montáži

Монтажная инструкция

220V
240V

CE




IP66









R&TTE
868MHz<5mW






IK 08

	LINE	W +/-10%	LED	EL		
LED	GRN16-2S/830	17	16	●	●	6.l
LED	GRN20-2S/740	19	16	●	●	6.l
LED	GRN21-2S/657	20	16	●	●	6.l
LED	GRN24-2S/830	25	24	●	●	6.l
LED	GRN29-2S/740	27	24	●	●	6.l
LED	GRN31-2S/657	29	24	●	●	6.l
LED	ECO23-2S/830	24	16	●	●	6.l
LED	ECO28-2S/740	28	16	●	●	6.l
LED	ECO30-2S/657	29	16	●	●	6.l
LED	ECO35-2S/830	35	24	●	●	6.l
LED	ECO43-2S/740	40	24	●	●	6.l
LED	ECO45-2S/657	40	24	●	●	6.l

Mini Iridium LED BGS 45 I







D7 I-10V

Number of LED	GreenLine Ecoline
16	OK only for 7-10V
24	●


D9 DALI

DALI
Digital Addressable Lighting Interface


Number of LED	GreenLine Ecoline	GreenLine Ecoline
16	OK only for 178-255	OK only for 241-255
24	●	●

DYNADIMMER


DD1/DDF1
Road 40% saving



DD2/DDF2
Road 32% saving



DD3/DDF3
Road 50% saving



RF

