

Low-bay 200 series

HCK 200




Mounting instruction 安装说明

4441 000 64871






Type No. 型号	Lamp 光源	Voltage/ Frequency 电压/频率	kg
HCK200 1XHPI-T 250W HCK200 1XHPI-T 250W K HCK200 1XHPI-T 250W 240V HCK200 1XHPI-T 250W 240V K	HPI-T 250W	220V/50Hz 220V/50Hz 240V/50Hz 240V/50Hz	8.5 Kg
HCK200 1XSON-T 250W HCK200 1XSON-T 250W K HCK200 1XSON-T 250W 240V HCK200 1XSON-T 250W 240V K	SON-T 250W	220V/50Hz 220V/50Hz 240V/50Hz 240V/50Hz	9.2 Kg
HCK200 1XSON-T 150W HCK200 1XSON-T 150W K HCK200 1XSON-T 150W 240V HCK200 1XSON-T 150W 240V K	SON-T 150W	220V/50Hz 220V/50Hz 240V/50Hz 240V/50Hz	8.3 Kg
HCK200 1XCDM-TT 250W HCK200 1XCDM-TT 250W K HCK200 1XCDM-TT 250W 240V HCK200 1XCDM-TT 250W 240V K	CDM-TT 250W	220V/50Hz 220V/50Hz 240V/50Hz 240V/50Hz	9.2 Kg
HCK200 1XCDM-TT 150W HCK200 1XCDM-TT 150W K HCK200 1XCDM-TT 150W 240V HCK200 1XCDM-TT 150W 240V K	CDM-TT 150W	220V/50Hz 220V/50Hz 240V/50Hz 240V/50Hz	8.3 Kg
HCK200 MAX250W-E40 HCK200 MAX100W-E27	ML MAX 250W ML MAX 100W	220V/50Hz-240V/50Hz	5.5 Kg
FCK200 1XPL-H/4P 120W	PL-H 120W	220V/50-60Hz-240V/50-60Hz	5.5 Kg

Surface mounted 吸顶安装










Remark: HCK200 MAX250W-E40, HCK200 MAX100W-E27 and FCK200 1XPL-H/4P 120W are IP23, no glass;
注意: HCK200 MAX250W-E40, HCK200 MAX100W-E27 and FCK200 1XPL-H/4P 120W这三款没有玻璃, 为IP23。

1





Philips Lighting Luminaires (Shanghai) Co., Ltd.
Address: No. 2688, Huyl Road, Jiading, Shanghai, China
Postalcode: 201801
飞利浦灯具(上海)有限公司
地址: 中国上海市嘉定区马陆镇沪宜公路2688号
邮编: 201801

PHILIPS






Suspension mounted 悬挂安装



Remark: HPK200 MAX250W-E40, HPK200 MAX100w-E27 and FPK200 1XPL-H/4P 120W are IP23, no glass;
Accessory ZDK200CH, need to be ordered separately


注意: HPK200 MAX250W-E40, HPK200 MAX100w-E27 and FPK200 1XPL-H/4P 120W这三款没有玻璃, 为IP23,
附件ZDK200CH可根据实际情况选择安装, 需要分开订购

1





Tighten the nut
拧紧螺母



In order to adjust the suspension
height, screw up or down
上下调节螺母, 平衡悬挂



2




External Dia.: $\varnothing 9.0 - 12 \text{ mm}$




Power cable go through the rubber
电源线穿过橡胶接头





3






4








After the installation, it must look like this
旋紧后, 应与该图一致






Recessed mounted 嵌入安装









- 10 The hook should be on the same side as the notch of the frame
挂钩和外框的缺口在同一侧




- 11 Please ensure the hook is tight
安装后请确保该卡勾卡紧





- 12 Lamp installation
安装光源



- 13 Please hold the glass when open it
打开玻璃时，请用手托住玻璃



- 14 Please ensure the hook is tight
安装后请确保该卡勾卡紧



1. Please turn off the power before maintenance and lamp replacement.

须断开电源后，才能维修和更换光源。

2. The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.

灯具应由有资格的电工安装，接线要符合IEE电气标准或国家标准。

3. The luminaire shall, under no circumstance, be covered with insulation matting or similar material.

灯具不适合被隔热或类似材料覆盖。

