

READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE

This fixture is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

INSTRUCTION SHEET NO.

IS:9100

R1095 Page 1 of 2

INSTALLATION INSTRUCTIONS RADIUS™ TRACK LIGHTING

IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS

RADIUS TRACK IS TO BE SUPPLIED BY A SINGLE BRANCH CIRCUIT 120 VOLT, 60HZ. THE MAXIMUM CAPACITY IS 20 AMPS PER CIRCUIT. WHEN INSTALLING THE TRACK DO NOT EXCEED THE CAPACITY OF THE CIRCUIT BREAKERS IN THE DWELLING. THE TRACK IS POLARIZED AND CONTINUOUSLY GROUNDED THROUGHOUT. USE ONLY FIXTURES IDENTIFIED FOR USE WITH LYTESPAN TRACK.

WHEN INSTALLING OR USING THIS TRACK SYSTEM, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- READ ALL INSTRUCTIONS.
- THIS TRACK SYSTEM IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND LOCAL OR FEDERAL CODE SPECIFICATIONS.
- TO PREVENT ELECTRICAL SHOCK TURN OFF ELECTRICITY AT FUSE BOX BEFORE INSTALLING THE TRACK OR ADDING TO OR CHANGING THE CONFIGURATION OF THE TRACK.
- DO NOT INSTALL THIS TRACK IN WET OR DAMP LOCATIONS.
- OBSERVE POLARITY. WHITE SUPPLY LEAD (NEUTRAL) TO CONTACT MARKED "NEUT" IN 9100 SERIES FEED CONNECTORS.
- DO NOT INSTALL ANY PART OF THE TRACK SYSTEM LESS THAN 5 FEET ABOVE THE FLOOR.
- DO NOT INSTALL ANY FIXTURE ASSEMBLY CLOSER THAN 6 INCHES FROM ANY CURTAIN, OR SIMILAR COMBUSTIBLE MATERIAL.
- DO NOT ATTEMPT TO ENERGIZE ANYTHING OTHER THAN TRACK LIGHTING FIXTURE ON THE TRACK. TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT ATTEMPT TO CONNECT POWER TOOLS, EXTENSION CORDS, APPLIANCES AND THE LIKE TO THE TRACK.
- DO NOT USE POWER CORDS OR CONVENIENCE RECEPTACLE ADAPTERS ON THE TRACK.
- DO NOT EXCEED 4 FEET BETWEEN MOUNTING SCREWS.
- DO NOT MOUNT TRACK BY CABLES, USE SOLID STEMS 9184, 9185 OR 9186 ONLY.
- DO NOT EXCEED 4 FEET BETWEEN STEMS WHEN PENDANT MOUNTING TRACK.

SAVE THESE INSTRUCTIONS