

INSTALLATION INSTRUCTIONS

IMPRESSIONS

BEDLIGHT SERIES

CAUTION! – READ THIS FIRST
IMPORTANT SAFETY INSTRUCTIONS

- Carefully read the instructions pertaining to your fixture. If you have any questions regarding the proper installation or local codes, consult a qualified electrician.
- This fixture employs a grounded-type receptacle and is not intended for connection to a two-wire, ungrounded source of supply.
- Injury to persons and damage to the fixture and/or mounting surface may result if the fixture is pulled from the surface. To reduce the likelihood of such injury or damage, mount only on a surface that is mechanically sound.
- To avoid shock hazard, do not work with live electrical wires.
- Install fixture in dry, indoor applications only.
- Do not install outdoors or in applications other than intended use.
- Install and wire fixture in locations in accordance with all national, state, and local codes.

WARNING: RISK OF FIRE AND ELECTRIC SHOCK.
MIN. 90°C SUPPLY CONDUCTORS.



WARNING: THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.



CAUTION: THE INSTALLATION AND SERVICING OF THIS PRODUCT SHOULD BE PERFORMED BY A QUALIFIED ELECTRICIAN OR SERVICE PERSONNEL
ATTENTION : L'INSTALLATION ET L'ENTRETIEN DE CE PRODUIT DOIVENT ÊTRE EFFECTUÉS PAR UN ÉLECTRICIEN OU UN MEMBRE DU PERSONNEL QUALIFIÉ.

INSTALLATION

The Impressions Bedlight Series Fixture comes completely assembled from the factory. Installing the fixture is a three-step procedure: Mounting the Housing, Connecting the Power, and Installing the Tray.

Mounting the Housing

1. Remove the top diffuser by lifting it up off the fixture.
2. Refer to Figure 1 to remove the bottom diffuser. Use the two clips and pull the diffuser toward the front of the fixture until the back edge is released from the slot. Grasp the back edge of the diffuser and remove it from the fixture.




Figure 1

3. Refer to Figure 2, and remove and retain the two screws securing the tray to the housing.
4. Lift out the tray from the housing and put it in a safe place.




Figure 2

NOTE:

Two key-hole mounting slots are provided for easy mounting. Use appropriate hardware for the weight of the fixture when mounting.

CAUTION: Electrical luminaires are designed for permanent installation in ordinary (Non-Hazardous) locations in accordance with the National Electrical Code and all applicable local codes. Do not use in areas of limited ventilation or in high ambient enclosures. The lamp and luminaire operate at high temperatures, contact with combustible materials can cause fire and personal contact can cause severe burns.

ATTENTION: Ce luminaire a été conçu pour une installation permanente dans un emplacement régulier (non dangereux) et en conformité avec le Code électrique canadien et codes locaux applicables. Ne jamais installer dans un endroit où la ventilation est limitée ou dans des boîtiers où la température ambiante est très élevée. La lampe et le luminaire fonctionnent à des températures élevées, un contact avec des matériaux combustibles peut engendrer un incendie et un contact corporel peut causer de sévères brûlures.

PHILIPS

Philips Lighting North
America Corporation
200 Franklin Square Drive
Somerset, NJ 08873, USA
Phone: 855-486-2216
philips.com/luminaires

Philips Lighting Canada Ltd.
281 Hillmount Road
Markham ON, Canada L6C 2S3
Phone: 800-668-9008
philips.com/luminaires

443580004630 JUNE, 2013

PAGE 1 OF 2

INSTALLATION INSTRUCTIONS

CAUTION: THE INSTALLATION AND SERVICING OF THIS PRODUCT SHOULD BE PERFORMED BY A QUALIFIED ELECTRICIAN OR SERVICE PERSONNEL
ATTENTION : L'INSTALLATION ET L'ENTRETIEN DE CE PRODUIT DOIVENT ÊTRE EFFECTUÉS PAR UN ÉLECTRICIEN OU UN MEMBRE DU PERSONNEL QUALIFIÉ.

5. Locate housing in desired mounting location making sure that wiring hole in housing is in correct position to bring in power wires. Mark the location of the two mounting screws by tracing through the key slots in the housing. (Drill holes if necessary in slot sections of tracing.)
6. Place fixture housing in mounting position and attach to wall. Be sure housing is securely mounted.
7. Connect supply conduit to conduit hole in housing, or if mounted at a conduit box, pull wires through hole.

Connecting the Power

WARNING: BE CERTAIN THAT POWER IS TURNED OFF BEFORE CONNECTING FIXTURE TO SUPPLY LINES. LIVE WIRES PRESENT A POTENTIAL FATAL SHOCK HAZARD.

The Impressions Bedlight Fixtures are internally wired at the factory. A four-wire quick disconnect plug is provided for connection to supply wiring. See Figures 3 for wiring diagram.




Figure 3

NOTES:

The quick-disconnect plug comes pre-wired with four wires. The black and white wires connect to "hot" and "neutral" supply wires. The yellow and red wires are provided to accommodate optional switching.

Be sure that all connections are secure. Be sure that wirenuts are tight and no strands of wire are exposed.

1. Disconnect the quick-disconnect plug.
2. Connect the black wire from the quick-disconnect plug to the "hot" supply wire (usually black) and the white wire from the quick-disconnect plug to the "neutral" supply wire (usually white). Secure with wire nuts.

3. Connect the supply "ground" wire to the nut provided on the fixture housing

Installing the Tray

NOTE: Before installing the tray, connect the quick-disconnect plug. The plug is keyed so that it cannot be connected incorrectly. Push the two halves of the plug together until a click is heard.

1. If the fixture is equipped with the optional four way pull-switch, drop cord through hole provided in housing.
2. Carefully drop the tray into the housing, making sure that all wiring is tucked neatly into tray.
3. Make sure that the pull switch cord works freely and the convenience outlet (if so equipped) is properly positioned.
4. Secure the tray to the housing with the two screws provided.
5. Install the top diffuser by placing it on the top of the fixture.
6. Install the bottom diffuser:
 - a. Insert front edge of the diffuser into slot in the front of the fixture.
 - b. Use the two clips and push the diffuser toward the front of the fixture until the back edge can be slipped into the slot at the back of the fixture.
 - c. Work the entire length of the back edge of the diffuser into the back slot of the fixture.

CHANGING LAMPS

NOTE: The Impression Series Fixture is equipped with T8 lamps. Remove diffuser to gain access to lamp(s).

1. Turn off power to fixture.
2. Rotate the lamp approximately 1/4 turn to disconnect from sockets.
3. Slide pins out of socket at each end of lamp.
4. Position new lamp so pins are aligned vertically in sockets at each end of lamp.
5. Install lamp completely by rotating a full 1/4 turn from loose position.
6. Test new lamp(s) by applying power, and reinstall diffuser.

CAUTION: Electrical luminaires are designed for permanent installation in ordinary (Non-Hazardous) locations in accordance with the National Electrical Code and all applicable local codes. Do not use in areas of limited ventilation or in high ambient enclosures. The lamp and luminaire operate at high temperatures, contact with combustible materials can cause fire and personal contact can cause severe burns.

ATTENTION: Ce luminaire a été conçu pour une installation permanente dans un emplacement régulier (non dangereux) et en conformité avec le Code électrique canadien et codes locaux applicables. Ne jamais installer dans un endroit où la ventilation est limitée ou dans des boîtiers où la température ambiante est très élevée. La lampe et le luminaire fonctionnent à des températures élevées, un contact avec des matériaux combustibles peut engendrer un incendie et un contact corporel peut causer de sévères brûlures.

PHILIPS

Philips Lighting North
America Corporation
200 Franklin Square Drive
Somerset, NJ 08873, USA
Phone: 855-486-2216
philips.com/luminaires

Philips Lighting Canada Ltd.
281 Hillmount Road
Markham ON, Canada L6C 2S3
Phone: 800-668-9008
philips.com/luminaires